



ProLinX[®]

CC-Link

ProLinX Gateway

CC-Link version 1.10 Local Station &
Intelligent Device

February 15, 2021

Your Feedback Please

We always want you to feel that you made the right decision to use our products. If you have suggestions, comments, compliments or complaints about our products, documentation, or support, please write or call us.

How to Contact Us

ProSoft Technology, Inc.

+1 (661) 716-5100

+1 (661) 716-5101 (Fax)

www.prosoft-technology.com

support@prosoft-technology.com

Copyright © 2021 ProSoft Technology, Inc. All rights reserved.

CC-Link Driver Manual

February 15, 2021

ProSoft Technology[®], ProLin[®], inRAx[®], ProTalk[®], and RadioLin[®] are Registered Trademarks of ProSoft Technology, Inc. All other brand or product names are or may be trademarks of, and are used to identify products and services of, their respective owners.

ProSoft Technology[®] Product Documentation

In an effort to conserve paper, ProSoft Technology no longer includes printed manuals with our product shipments. User Manuals, Datasheets, Sample Ladder Files, and Configuration Files are provided on the enclosed CD-ROM in Adobe[®] Acrobat Reader file format (.PDFs). These product documentation files may also be freely downloaded from our web site:
www.prosoft-technology.com

Important Installation Instructions

Power, Input, and Output (I/O) wiring must be in accordance with Class I, Division 2 wiring methods, Article 501-4 (b) of the National Electrical Code, NFPA 70 for installation in the U.S., or as specified in Section 18-1J2 of the Canadian Electrical Code for installations in Canada, and in accordance with the authority having jurisdiction. The following warnings must be heeded:

WARNING - EXPLOSION HAZARD - SUBSTITUTION OF COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS I, DIV. 2;

WARNING - EXPLOSION HAZARD - WHEN IN HAZARDOUS LOCATIONS, TURN OFF POWER BEFORE REPLACING OR WIRING MODULES

WARNING - EXPLOSION HAZARD - DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NON-HAZARDOUS.

THIS DEVICE SHALL BE POWERED BY CLASS 2 OUTPUTS ONLY.

ProLinx® Products Warnings

WARNING – EXPLOSION HAZARD – DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NON-HAZARDOUS.

AVERTISSEMENT – RISQUE D'EXPLOSION – AVANT DE DÉCONNECTER L'EQUIPMENT, COUPER LE COURANT OU S'ASSURER QUE L'EMPLACEMENT EST DÉSIGNÉ NON DANGEREUX.

ProLinx Gateways with Ethernet Ports

Series C ProLinx™ Gateways with Ethernet ports do **NOT** include the HTML Web Server. The HTML Web Server must be ordered as an option. This option requires a factory-installed hardware addition. The HTML Web Server now supports:

- 8 MB file storage for HTML files and associated graphics files (previously limited to 384K)
- 32K maximum HTML page size (previously limited to 16K)

PLX Markings

Label Markings

ATEX

<Ex>

II 3 G

Ex nA IIC T4

-20°C ≤ Ta ≤ 50°C

II – Equipment intended for above ground use (not for use in mines).

3 – Category 3 equipment, investigated for normal operation only.

G – Equipment protected against explosive gasses.

Agency Approvals and Certifications

ATEX EN 60079-0:2009
 EN 60079-15:2010

CE IEC 1131-2:1
 EN60950:2000
 EN55011:1998, Class A
 EN61000-6-2:1998
 EN50021:1999

 IEC 60950-1:2005-Ed2
 EN60950-1:2006
CB Safety CB243333-2393116



Contents

| | |
|---|-----------|
| Your Feedback Please..... | 2 |
| How to Contact Us..... | 2 |
| ProSoft Technology® Product Documentation..... | 2 |
| Important Installation Instructions..... | 3 |
| ProLinx® Products Warnings..... | 3 |
| ProLinx Gateways with Ethernet Ports..... | 3 |
| PLX Markings..... | 3 |
| Agency Approvals and Certifications..... | 4 |
| 1 CC-Link | 7 |
| 1.1 Internal Database..... | 8 |
| 1.2 CC-Link Access to Gateway Database..... | 9 |
| 2 Installing ProSoft Configuration Builder Software | 11 |
| 3 Configuring the Gateway | 13 |
| 3.1 Using the Online Help..... | 13 |
| 3.2 Adding a Module..... | 14 |
| 3.3 Configuring Module Parameters..... | 15 |
| 3.4 Creating Optional Comment Entries..... | 15 |
| 3.5 CC-Link Protocol Configuration..... | 16 |
| 3.5.1 [CCLK Config]..... | 16 |
| 3.6 Configuring Transient Messages..... | 19 |
| 3.6.1 [CCLink Command Attribute x]..... | 19 |
| 3.6.2 Example Commands..... | 26 |
| 3.7 Using the CommonNet Data Map..... | 41 |
| 3.7.1 [Data Map]..... | 42 |
| 3.8 Printing a Configuration File..... | 45 |
| 3.9 Downloading a File from PC to the Module..... | 46 |
| 4 Diagnostics and Troubleshooting | 47 |
| 4.1 Using ProSoft Configuration Builder (PCB) for Diagnostics..... | 47 |
| 4.1.1 Required Hardware..... | 47 |
| 4.1.2 Using the Diagnostic Window in ProSoft Configuration Builder..... | 48 |
| 4.1.3 Navigation..... | 50 |
| 4.2 LED Indicators..... | 51 |
| 4.2.1 Base Module LEDs..... | 51 |
| 4.2.2 CC-Link Interface-Specific LEDs..... | 51 |
| 4.3 Status Data..... | 52 |
| 4.4 Error Data..... | 65 |
| 5 Reference | 76 |
| 5.1 General Overview..... | 76 |
| 5.2 CC-Link Overview..... | 77 |

| | | |
|----------|---|------------|
| 5.2.1 | Types of CC-Link Data Transfers | 77 |
| 5.2.2 | Types of CC-Link Slave Stations | 78 |
| 5.3 | ProLinx CCLINK User Data Memory | 79 |
| 5.3.1 | ProLinx CCLINK Memory Map Overview | 79 |
| 5.3.2 | ProLinx CCLINK Memory Area Breakdown by Logical Station | 81 |
| 5.3.3 | ProLinx Local Station Network Data Area Breakdown | 82 |
| 5.4 | CC-Link Cyclic Data Concepts | 85 |
| 5.5 | CC-Link Transient Data Messaging Concepts | 88 |
| 5.5.1 | General | 88 |
| 5.5.2 | CCLINK Transient Data Message Memory Areas | 89 |
| 5.6 | Specifications..... | 90 |
| 5.6.1 | Functional Specifications - CC-Link..... | 90 |
| 5.7 | Conformance Testing | 91 |
| 5.7.1 | General Specifications..... | 91 |
| 5.7.2 | Using ProSoft Configuration Builder..... | 91 |
| 5.7.3 | Hardware Specifications | 92 |
| 5.8 | RS-232 Configuration/Debug Port | 93 |
| 5.9 | DB9 to Mini-DIN Adaptor (Cable 09) | 94 |
| 5.10 | CC-Link Port | 95 |
| 6 | Support, Service & Warranty | 97 |
| | Contacting Technical Support | 97 |
| 6.1 | Return Material Authorization (RMA) Policies and Conditions | 99 |
| 6.1.1 | Returning Any Product..... | 99 |
| 6.1.2 | Returning Units Under Warranty..... | 99 |
| 6.1.3 | Returning Units Out of Warranty..... | 100 |
| 6.2 | LIMITED WARRANTY | 100 |
| 6.2.1 | What Is Covered By This Warranty | 101 |
| 6.2.2 | What Is Not Covered By This Warranty..... | 101 |
| 6.2.3 | Disclaimer Regarding High Risk Activities..... | 102 |
| 6.2.4 | Intellectual Property Indemnity | 102 |
| 6.2.5 | Disclaimer of all Other Warranties | 103 |
| 6.2.6 | Limitation of Remedies ** | 103 |
| 6.2.7 | Time Limit for Bringing Suit..... | 103 |
| 6.2.8 | No Other Warranties..... | 103 |
| 6.2.9 | Allocation of Risks | 103 |
| 6.2.10 | Controlling Law and Severability | 104 |
| | Index | 105 |

1 CC-Link

In This Chapter

- ❖ Internal Database 8
- ❖ CC-Link Access to Gateway Database 9

The CC-Link protocol driver acts as a Local Station or Intelligent Device, which enables easy connection to the CC-Link Master-controlled network for data transfer. Configuration options allow the gateway to occupy up to four (4) stations on the CC-Link network. Transient Messaging capability increases overall I/O data transfer capacity by more than 8,000 words. When configured as a Local Station, the gateway allows read-only viewing of the entire CC-Link Master cyclic database from all configured slaves on the CC-Link network.

The module is a stand-alone DIN-rail mounted protocol gateway that provides one CC-Link TE-CON7 4P port and an Ethernet RJ45 connector interface.

CC-Link (Control & Communication Link) is an open-standard-based communication protocol that enables easy connection to Mitsubishi PLCs, and provides fast, reliable communication on this fieldbus network used in automation and process control. CC-Link is the dominant protocol used in Asia, and is rapidly gaining acceptance worldwide.

Interoperability

CC-Link technology is based on the use of an Application Specific Integrated Circuit (ASIC) available from Mitsubishi Electric Automation.

Conformance Testing


Conformance testing through the CC-Link Partner Association (CLPA) ensures that devices meet the performance specifications necessary to become CC-Link certified.

Document Conventions

In this User Manual, whenever you see "CCLINK", this refers to the ProLinX CCLINK protocol driver implementation. Whenever you see "CC-Link", this refers to the protocol in general or to the protocol implementation on other manufacturers' systems. These difference references allow an easy way to identify exactly which CCLINK/CC-Link protocol implementation is being discussed at any point in the document.

1.1 Internal Database

The module contains an internal database, which is shared between all ports on the gateway. The database is also used to pass information from devices on one network to devices on another network. Data from devices connected to one communications port can be viewed and controlled by devices connected to another port.



You can also configure the internal database, in combination with the Memory Map feature to retrieve and view status and error information generated by the gateway.

1.2 CC-Link Access to Gateway Database

The CCLINK driver supports CC-Link slave functionality as a Local Station or Intelligent Device. Gateway-supported services permit CC-Link Master applications to read from and write to the gateway's internal database.

The internal database of the CC-Link gateway is used as the data source to respond to CC-Link Master read requests and as the data destination for receiving and holding data from CC-Link Master write requests. Access to the database depends on the command type from the remote Master, as well as whether the CCLINK driver has been configured to be a Local Station slave or an Intelligent Device slave.

Before you connect the gateway to a network, verify that the network connections are correct and that the gateway is correctly configured. You will use ProSoft Configuration Builder (PCB) to configure the gateway and to transfer the configuration files to and from the gateway.

2 Installing ProSoft Configuration Builder Software

You must install the *ProSoft Configuration Builder (PCB)* software to configure the gateway. You can always get the newest version of *ProSoft Configuration Builder* from the ProSoft Technology website.

To install ProSoft Configuration Builder from the ProSoft Technology website

- 1 Open your web browser and navigate to <http://www.prosoft-technology.com/pcb>
- 2 Click the link at the *Current Release Version* section to download the latest version of *ProSoft Configuration Builder*.
- 3 Choose **SAVE** or **SAVE FILE** when prompted.
- 4 Save the file to your *Windows Desktop*, so that you can find it easily when you have finished downloading.
- 5 When the download is complete, locate and open the file, and then follow the instructions on your screen to install the program.

If you do not have access to the Internet, you can install *ProSoft Configuration Builder* from the *ProSoft Solutions Product CD-ROM*, included in the package with your gateway.

To install ProSoft Configuration Builder from the Product CD-ROM

- 1 Insert the *ProSoft Solutions Product CD-ROM* into the CD-ROM drive of your PC. Wait for the startup screen to appear.
- 2 On the startup screen, click **PRODUCT DOCUMENTATION**. This action opens a *Windows Explorer* file tree window.
- 3 Click to open the **UTILITIES** folder. This folder contains all of the applications and files you will need to set up and configure your gateway.
- 4 Double-click the **SETUP CONFIGURATION TOOL** folder, double-click the **PCB_*.EXE** file and follow the instructions on your screen to install the software on your PC. The information represented by the "*" character in the file name is the *PCB* version number and, therefore, subject to change as new versions of *PCB* are released.

Note: Many of the configuration and maintenance procedures use files and other utilities on the CD-ROM. You may wish to copy the files from the *Utilities* folder on the CD-ROM to a convenient location on your hard drive.

3 Configuring the Gateway

In This Chapter

| | |
|--|----|
| ❖ Using the Online Help..... | 13 |
| ❖ Adding a Module | 14 |
| ❖ Configuring Module Parameters | 15 |
| ❖ Creating Optional Comment Entries | 15 |
| ❖ CC-Link Protocol Configuration | 16 |
| ❖ Configuring Transient Messages | 19 |
| ❖ Using the CommonNet Data Map | 41 |
| ❖ Printing a Configuration File..... | 45 |
| ❖ Downloading a File from PC to the Module | 46 |

3.1 Using the Online Help


Most of the information needed to help you use *ProSoft Configuration Builder* is provided in a Help System that is always available whenever you are running *ProSoft Configuration Builder*. The Help System does not require an Internet connection.

To view the help pages, start *ProSoft Configuration Builder*, open the **HELP** menu, and then choose **CONTENTS**.

3.2 Adding a Module

Begin the process of creating your custom application configuration by selecting the module type of your ProLinX gateway.

- 1 Double-click the **DEFAULT MODULE** icon to open the *Choose Module Type* dialog box.



- 2 In the *Choose Module Type* dialog box, select the **MODULE** type.

Or

- 1 Open the **PROJECT** menu and choose **LOCATION**.
- 2 On the **LOCATION** menu, choose **ADD MODULE**.



To add a module to a different location

- 1 Right-click the **LOCATION** folder and choose **ADD MODULE**. A new *Module* icon appears.



Or


- 1 Select the **LOCATION** icon.
- 2 From the **PROJECT** menu, select **LOCATION**, and then select **ADD MODULE**.

3.3 Configuring Module Parameters

- 1 Click the **[+]** sign next to the module icon to expand gateway information.
- 2 Click the **[+]** sign next to any  icon to view gateway information and configuration options.
- 3 Double-click any  icon to open an *Edit* dialog box.
- 4 To edit a parameter, select the parameter in the left pane and make your changes in the right pane.
- 5 Click **OK** to save your changes.

3.4 Creating Optional Comment Entries

- 1 Click the **[+]** to the left of the  *Comment* icon to expand the module comments.
- 2 Double-click the  *Module Comment* icon. The *Edit - Module Comment* dialog box appears.



- 3 Enter your comment and click **OK** to save your changes.

3.5 CC-Link Protocol Configuration

CC-Link Protocol Configuration consists of the following sections:

- CCLK Config (page 16). This section defines the protocol features, gateway memory, and port settings for the protocol
- CCLink Commands Attribute x (page 19). The CCLINK driver can use Transient Messages (page 88), in the form of CCLink Command Attributes, to communicate with other devices on the CC-Link network.

The following illustration shows the CC-Link section of the gateway configuration. The rest of this chapter describes each parameter, with default and suggested values.




```

[CCLK Config]
Enable                : Enable      #
Station Number       : 1           #
Slave Type            : Local Station #
Transmission Speed   : 625 Kbps    #
Station Occupied     : 1           #
Times Setting        : 1           #
Alive Check          : Enable      #

[CCLink Commands]
START
# CCLink Commands Attribute 4
# Enable      Internal Address  Trigger Register  Register Count  Swap Code
1  Disable    1300             0                0                No Change
END
    
```

3.5.1 [CCLK Config]

This section defines the protocol features, gateway memory, and port settings for the protocol. To edit this section, expand the **CC-LINK** icon in the Tree View, and then double-click the **CCLK CONFIG** tag.



Enable

0 (Disable)

1 (Enable)

This setting enables or disables the CCLINK serial port on the gateway. You must enable the port to use the CC-Link protocol.

Station Number

1 to 64 to identify the logical station

128 to place the logical station in standby mode

This value identifies stations on the CC-Link network. Each physical station must have a unique station number. You cannot assign the same station number to more than one station.

Note: Some CC-Link devices, including the ProLinx® CCLINK protocol gateway, allowing you to use up to four consecutive logical slave station addresses for each physical slave station. Refer to the *Stations Occupied* (page 18) parameter for more on this feature.

Slave Type

1 = Local Station.

A Local Station can perform Cyclic Data transmission between itself and the Master Station, as well as, perform Transient Message transmission between itself and the Master station or other Local Stations on the network.

2 = Intelligent Device.

In the CC-Link protocol specification, an Intelligent Device can perform Cyclic Data transmission and Transient Message transmission only between itself and the Master Station. An Intelligent device could not normally communicate directly with any other slave stations on the network. However, a CCLINK gateway configured as an Intelligent Device, can perform Transient Message transmissions to both the CC-Link network Master Station and to other slave stations on the network, operating as if it is configured as a Local Station.

Transmission Speed

Defines the transmission speed of the data link.

| Value |
|---------|
| 156kbps |
| 625kbps |
| 2.5Mbps |
| 5Mbps |
| 10Mbps |

Stations Occupied

1 to 4

Configures the number of logical slave stations used by a single physical slave station on the network. Choose from one to four stations, depending on the amount of Cyclic Data to be transmitted.

Times Setting

1 for all CC-Link versions

Note: The CCLINK driver currently supports only CC-Link specification version 1.10 and below. Therefore, no other *Times Settings* are possible.

Alive Check

Configures whether or not to perform Alive Check:

- Enable
- Disable

This function enables the check to assure normal operation between the driver software and the Q50BD-CCV2 CC-Link hardware interface board.

3.6 Configuring Transient Messages


Transient Message Commands send non-periodic (asynchronous) data between the Master Station, Local Stations, and Intelligent Devices. The gateway can issue Transient Messages whether it is configured as a Local Station or as an Intelligent Device. For additional information, refer to CC-Link Transient Messaging Concepts (page 88).

3.6.1 [CCLink Command Attribute x]


The [CCLINK COMMAND ATTRIBUTE 4] and [CCLINK COMMAND ATTRIBUTE 5] sections of the configuration file allow you to selectively send Transient Messages between the gateway, the CC-Link Master and other Local Stations and Intelligent Devices on the CC-Link network. The gateway executes the commands in numerical order. "Disabled" commands are skipped.

To configure Transient Message commands, double-click the **COMMAND ATTRIBUTE 4** or **COMMAND ATTRIBUTE 5** sections of the gateway configuration in PCB.

To add a command to the list, click the **ADD ROW** button.



To edit a command, click the **EDIT ROW** button. This action opens the **EDIT** dialog box, where you configure the parameters for the command.



Enable

- 0 = disable
- 1 = conditional read
- 2 = conditional write

The Enable parameter allows you to control execution of each command:

Internal Address

0 to 9998

This is a register address in the gateway’s internal database. If the command is a read command, this is the starting address where data will be stored.

Trigger Register

0 to 9999

This is a register address in the gateway’s internal database that contains a trigger value that will control the execution of this command.

The trigger value held in the *Trigger Register* determines when the command will be sent. The command will not be sent as long as the *Trigger Register* contains a value of zero (0). The command will be sent one time when the value in the *Trigger Register* changes from zero to any non-zero value. After the command is sent, the *Trigger Register* value is automatically reset to zero (0).

Note: In order for the *Trigger Register* to control command execution, the *Enable* parameter must be set to 1 (Conditional Read Command) or 2 (Conditional Write Command), and the *Register Count* must be greater than zero (0).

Register Count

0 to disable to 480

This is the number of registers to read or write. Set this value to 0 to disable the command.

Swap Code

0, 1, 2, 3

This parameter defines the byte order of each four-byte group of data received. This parameter is helpful when dealing with floating-point or other multi-register values, as there is no standard byte order for storing these data types. The following table describes the values and their associated operations:

| Swap Code | Description |
|------------------|---|
| 0 | None - No Change is made in the byte ordering (1234 = 1234) |
| 1 | Words - The words are swapped (1234=3412) |
| 2 | Words & Bytes - The words are swapped then the bytes in each word are swapped (1234=4321) |
| 3 | Bytes - The bytes in each word are swapped (1234=2143) |

Node Address

1 to 64, 128, 255

The Node Address parameter sets the CC-Link Station Number of the device that will be the target for this command.

- Slave Station: 1 to 64 (01h to 40h, h = hexadecimal, or base 16, numbering system)
- Master Station: 0 (00h)
- Standby Master Station: 128 (80h)
- Broadcast to All Station: 255 (FFh)

Attribute Code

4 or 5

There are two command parameters that control what kind of Transient Message the gateway will send, the Command *Attribute Code* and the Command *Access Code*.

Note: These values are provided for information only, are part of the command, and cannot be modified.

Attribute Code 4 - Use for accessing CC-Link data that exists in the CC-Link communication card memory buffer that is common for all CC-Link network stations. You must specify the address offset into this common network memory buffer according to the logical station address and type of data that you wish to access from a particular station. This data is essentially the same as the Network Cyclic Data that the firmware already copies to the Local Station Database in gateway addresses 0 to1300. Therefore, this *Attribute Code* will have limited practical application and has been included for protocol specification compliance.

Attribute Code 5 - Use for accessing CC-Link database memory on any station capable of receiving and sending Transient Messages. This *Attribute Code* is more useful than *Attribute Code 4* because it extends data access to a wider range of data types beyond common Cyclic Data and common buffer data. *Attribute Code 5* can be used to access timers, counters, link and status data, as well as input/output bit and registers, and more.

Access Code

Various values entered as hexadecimal codes

There are two command parameters that control what kind of Transient Message the gateway will send, the Command *Attribute Code* and the Command *Access Code*. Each of the two *Attribute Codes* have different *Access Codes* associated with them. Even though some of the same hexadecimal values are used as *Access Codes* for both *Attribute Codes*, it is the combined *Attribute Code/Access Code* pair which determine the exact type of command transmitted.

Which *Access Code* you can use in a command depends on the selected *Attribute Code*, 4 or 5, discussed above. Refer to the following tables for a description of the available *Access Codes* for each *Attribute Code*.

Access Codes for Attribute 4

| Device Contents | Access Code |
|--|--------------------|
| Buffer in the Intelligent Device Station | 00h |
| Random access buffer | 20h |
| Remote input | 21h |
| Remote output | 22h |
| Link special relay | 63h |
| Link special register | 64h |
| Remote register | 24h |

Access Codes for Attribute 5

| Device Contents | Name | Bit | Word | Unit | Access Code |
|---------------------------------|------|-----|------|-------------|-------------|
| Input relay | X | O | | Hexadecimal | 01h |
| Output relay | Y | O | | Hexadecimal | 02h |
| Internal relay | M | O | | Decimal | 03h |
| Latch relay | L | O | | Decimal | 83h |
| Link relay | B | O | | Hexadecimal | 23h |
| Timer (contact) | T | O | | Decimal | 09h |
| Timer (coil) | T | O | | Decimal | 0Ah |
| Timer (present value) | T | | O | Decimal | 0Ch |
| Retentive timer (contact) | ST | O | | Decimal | 89h |
| Retentive timer (coil) | ST | O | | Decimal | 8Ah |
| Retentive timer (present value) | ST | O | | Decimal | 8Ch |
| Counter (contact) | C | O | | Decimal | 11h |
| Counter (coil) | C | O | | Decimal | 12h |
| Counter (present value) | C | | O | Decimal | 14h |
| Data register | D | | O | Decimal | 04h |
| Link register | W | | O | Hexadecimal | 24h |
| File register | R | | O | Decimal | 84h |
| Special link relay | SB | O | | Hexadecimal | 63h |
| Special link register | SW | | O | Hexadecimal | 64h |
| Special relay | SM | O | | Decimal | 43h |
| Special register | SD | | O | Decimal | 44h |

Note: Device Contents (data areas or data types) other than those shown above cannot be accessed.

Transient Message Bit-level Access

Both *Command Attribute Code 4* and *Command Attribute Code 5* have *Command Access Codes* that allow transfer of binary, bit-level data. The following cautionary Note and Warning apply to all Transient Message Commands used to access binary or bit-level data types.

Note: Binary bit-level data may not be accessed as single or individual bits, but only in 16-bit, whole-word groupings. When accessing bit-level data, the bits will always be read or written starting on an even 16-bit word boundary in the target database. That is to say that all reads and writes will start at Bit 0 of the word address used in the command. For hexadecimal addresses, the right-most bit = 0 will indicate a word-level boundary bit address (0000h, 0010h, 01C0h, and so on). Therefore, when accessing a bit device (such as Input Relay, Output Relay, Timer (coil), Counter (contact), and so on), you must specify the *Offset Address* in the command as a word address by first converting any hexadecimal address to its decimal equivalent and then divide the bit address by 16. Next, drop any remainder (no decimal point fractions allowed) and the integer result of this division then becomes the *Offset Address* for the command.

Example: Input Relay 5Ah = 90 decimal / 16 = 5.625 = Bit 10 of register 5. *Offset[word] Address* = 5.

When dealing with hexadecimal (hex or h) addresses, a shortcut alternative to doing this calculation would be to drop the right-most digit in the hex address and convert the remaining digit or digits to their decimal equivalent.

Example: Timer (coil) 01CAh - Drop the A & convert 01Ch to decimal. *Offset[word] Address* = 28.

To access individual bits, you will have to read the entire word containing the bit or bits you wish to access. If you wish to change the value of specific bits, you will need read the entire word containing the bit or bits you wish to change, employ a bit-masking technique to change only the bits you want to change, and then write back the entire data word containing the changed bits.

WARNING: Anyone creating and using Transient Messages to write bit-level data must use extreme care must be exercised with any bit-masking procedure to avoid unwanted data changes that could result in unexpected equipment operation, which might cause damage to equipment or injury to personnel.

Offset Address

0 and up, always entered as a decimal (base 10) value

This parameter sets the address offset of a memory area in the CC-Link hardware memory buffer or in the memory database area on a remote station that will be affected by the command. The values to use here will vary based on the Command *Attribute Code*, Command *Access Code*, the type of data to be accessed, and the location of that data in the target data area or device.

Even though many CC-Link devices specify memory addresses using hexadecimal numbers, this parameter must always be entered into the PCB Command configuration as the decimal (base 10) equivalent of any hexadecimal address value. If necessary, convert any hexadecimal addresses to decimal numbers before entering the value into this parameter. For additional details, refer to Transient Message Bit-level Access (page 24).

Example: If X100h is the start of your Remote Inputs (RX data area) in a CC-Link Master PLC, then:

- The *Offset Address* to the beginning of the RX data area will be 0 to read the data from X100h through X10Fh.
- To read from the Master RX bit addresses starting at X110h through X11Fh use *Offset Address 1*.
- To read X120h through X12Fh use *Offset Address 2*, and so on.

Comment

0 to 35 alphanumeric characters

3.6.2 Example Commands

The following command examples show how to read and write data from the CC-Link network using Transient Messages. These examples show several of the most typical types of Transient Messages you might need to use. They are not meant to be an exhaustive reference of all possible *Attribute Code/Access Code* combinations, only to present a few, well-chosen, representative ones.


Command Attribute Code 4

Command *Attribute Code 4* is used to access the network data buffer on the CC-Link hardware interface card on the ProLinx gateway or on a remote Station. The lowest *Offset Address* for all listed *Access Codes* will be zero, except for *Access Code 24h*, which must be treated differently.


An *Access Code 24h* write command accesses the write register area of the data buffer, which starts at *Offset Address 0 (00h)*. An *Access Code 24h* read command accesses the read register area of the data buffer, which starts at *Offset Address 256 (100h)*.

For a list of the *Access Codes* available for *Attribute Code 4*, refer to *Access Codes for Attribute 4* (page 22).

Note: *Access Codes 21h, 22h, and 63h* access binary bit data. Refer to note on *Bit-level Access* (page 24).



You can view the Command List from the gateways Config/Debug menu. The following illustration shows an example Command List for commands 0 to 9.




To execute any command entered in the list, use the database *Trigger Register*, which can be controlled by the other protocol on the gateway. Set the *Trigger Register* to any non-zero value to cause the command to be transmitted. The *Trigger Register* value will reset to zero every time the associated command is executed.


Conditional Read Example

This example issues a Transient Message conditional read with *Attribute Code 4/Access Code 24h*. This command attempts to read data from the Master at offset 256 (0100 Hex), which is the start of the RWr register area in the buffer. Data will be placed in the gateway at address 6000. To execute this command, change register 5100 to any non-zero value.


The following illustration shows the command in ProSoft Configuration Builder.



The following illustration shows the source data in a Mitsubishi PLC (notice the Device addresses in the Mitsubishi are shown as hexadecimal values preceded by the letter "D". Each address is a 16-bit register)




The following illustration shows the data in the gateway's database destination address 6000.




Remote Inputs Example

This example issues a Transient Message conditional read with *Attribute Code 4/Access Code 21h*, which reads the Remote Inputs (RX area). This command will read 16 inputs bits (1 register word), and will place the data in the gateway's database register 6008.


The following illustration shows the command in ProSoft Configuration Builder.



The following illustration shows the source data in a Mitsubishi PLC. Notice that the beginning of the RX data area in the Master is bit address X100. Because X100 is the first register of the RX data area, using *Offset Address* = 0 and *Access Code* = 21h in the PCB command will allow the command to read at the start of the RX data area in the Master.




The following illustration shows the source data in the gateway's database destination address 6008.




Entering the Command Offset Address


This is an example command for ProSoft Configuration Builder to show how to read Special Link Relay (bit-level data) from address SB60h using *Attribute Code 4/Access Code 63h*. For additional information on how to convert bit-level addresses into *Offset [word] Addresses*, refer to Transient Message Bit-level Access (page 24)



The following illustration shows the source data in a Mitsubishi PLC.



The following illustration shows the data in the gateway's database destination address 7002.




Command Attribute 5

This set of transient messages can be issued between the gateway and the Master. You can also issue these commands from the gateway to other slave stations on the network that can receive and respond to Transient Messages. Most of these examples show messages between a ProLinx gateway and a Mitsubishi PLC configured as a CC-Link Master.


For a complete list of potential *Access Codes*, refer to Access Codes for Attribute 5 (page 23).

Writing to the Remote Input RX Data Area


The following example shows how to send a conditional write command using *Attribute Code 5/Access Code 01h*, which writes to the Remote Input RX data area or a Local Station or the X data area in the Mitsubishi Master PLC.



The following illustration shows the source data to be sent to the Master PLC from gateway source address 0.



The following illustration shows the data in destination X20 (word offsets 2 and 3) in the Mitsubishi PLC.



Writing to Counters, Timers or Retentive Timers

Note Take special care when writing or reading from a Timer (T), Counter (C) or Retentive Timers (ST), especially when attempting to read their contacts and coils. Careless use of Transient Messages to these data types can cause PLC faults and/or total loss of CC-Link network communication.


The protocol is able to read contacts and coils only in word groupings of 16. A Transient Message command will read/write the first 16 contacts of the first 16 timers in one register in the database.

A message to read Timer, Counter, or Retentive Timer contacts starting at *Offset Address* = 0 with *Register Count* = 1 actually retrieves contacts for Timers 0-15. Retentive Timers and Counters work the same way as do write commands to the contacts or coils.


Access Codes for Attribute Code 5 to read or write to Counters, Timers or Retentive Timers are:

- 09 Hex
- 0A Hex
- 89 Hex
- 8A Hex
- 11 Hex
- 12 Hex


In this example, the following illustration shows a Conditional Write command using *Attribute Code 5/Access Code 09h*.



This message will retrieve data value 847 from gateway database locations 10 and 11, and write the first 32 contacts of the first 32 timers to the Mitsubishi PLC Master.




The following illustration shows the data in the Mitsubishi PLC after the command is executed.




Timers 0 to 31 contain the same data pattern as that from the gateway. The binary value of 847 decimal is 000001101001111.

Writing to the File Register Data Type


This example shows how to send a conditional write command using *Attribute Code 5/Access Code 84h*. This command writes to the File Register data type (R) from source address 0032 and 0033 in the gateway, to the destination registers R45 and R46 in the File Register data to the Mitsubishi PLC Master.



The following illustration shows the source data in the gateway to be sent to the Mitsubishi PLC Master.



The following illustration shows the data in the destination registers R45 and R46 in the Mitsubishi PLC Master.



Conditional Write Example to Other Than a Master Station


This example shows how to set up a conditional write with *Attribute Code 5/Access Code 24h*. This command will write data from the gateway to another Local Station (in this case, another ProLinx gateway) rather than writing to the Mitsubishi PLC Master Station.

In order to write to the correct offset and because Access Code 24h writes to the RWw data area of the destination station, you must know the start of the RWw data area in the destination Local Station.


Example: For this example, assume:

- 1 That you want to send a Transient Message to write data from your local ProLinx gateway to a remote ProLinx gateway
- 2 That the RWw data area of the remote gateway starts at gateway address 40
- 3 That the remote gateway is configured to occupy four logical stations
- 4 That each logical station uses four consecutive words in the RWs data area
- 5 That the first occupied address in the remote gateway is Station #2
- 6 And that you want to write to the *Node Address (Local Station) #5*, the fourth logical station in the Remote ProLinx gateway.


Therefore, because the R_W data area in the remote gateway begins at gateway database register 40, which would be *Offset Address* 40, and you are trying to write to the fourth logical station in that data area, then the destination *Offset Address* you will need to use in the command will be 52.



The following illustration shows the source data to be written from the gateway to Local Station #5 on the network.



The following illustration shows the data as written to the destination station.





3.7 Using the CommonNet Data Map

The *Data Map* section allows you to copy data between areas in the gateway's internal database. You can copy a maximum of 100 registers per *Data Map* command, and you can configure a maximum of 200 separate copy commands.

You can copy data from the error or status tables in upper memory to internal database registers in the *User Data memory* area.

You can rearrange the byte and/or word order during the copy process. For example, by rearranging byte or word order, you can convert floating-point values to the correct format for a different protocol.

You can also use the *Data Map* to condense widely dispersed data into one contiguous data block, making it easier to access.



3.7.1 [Data Map]

From Address

0 to highest Status Data address

The data area for CCLINK consists of registers 0000 to 9999. There is no special status area for the CCLINK driver.

For information on data areas and status areas for other protocols refer to the *ProLinX Reference Guide*.

To Address

0 to 9999

The destination for the copy is always within the Register Data area.

Register Count

1 to 100


This parameter specifies the number of registers to copy.

Swap Code

NO CHANGE, WORD SWAP, WORD AND BYTE SWAP, BYTE SWAP

You may need to swap the order of the bytes in the registers during the copy process in order to change the alignment of bytes between dissimilar protocols. This parameter is helpful when dealing with floating-point or other multi-register values, as there is no standard method of storage of these data types in slave devices.

The following table defines the values and their associated operations:



| Swap Code | Description |
|--------------------|--|
| No Swap | No change is made in the byte ordering (1234 = 1234) |
| Word Swap | The words are swapped (1234=3412) |
| Word and Byte Swap | The words are swapped, then the bytes in each word are swapped (1234=4321) |
| Bytes | The bytes in each word are swapped (1234=2143) |

Delay Preset

This parameter sets an interval for each *Data Map* copy operation. The value you put for the *Delay Preset* is not a fixed amount of time. It is the number of firmware scans that must transpire between copy operations.

The firmware scan cycle can take a variable amount of time, depending on the level of activity of the protocol drivers running on the ProLinx gateway and the level of activity on the gateway's communication ports. Each firmware scan can take from 1 to several milliseconds to complete. Therefore, *Data Map* copy operations cannot be expected to happen at regular intervals.

If multiple copy operations (several rows in the *Data map* section) happen too frequently or all happen in the same update interval, they could delay the process scan of the gateway protocols, which could result in slow data updates or missed data on communication ports. To avoid these potential problems, you should set the *Delay Preset* to different values for each row in the *Data Map* section and set them to higher, rather than lower, numbers.


For example, *Delay Preset* values below 1000 could begin to cause a noticeable delay in data updates through the communication ports. And you should not set all *Delay Presets* to the same value. Instead, use different values for each row in the Data Map such as 1000, 1001, and 1002 or any other different *Delay Preset* values you like. This will prevent the copies from happening concurrently and prevent possible process scan delays.

3.8 Printing a Configuration File

- 1 Select the module icon, and then click the right mouse button to open a shortcut menu.
- 2 On the shortcut menu, choose **VIEW CONFIGURATION**. This action opens the *View Configuration* window.
- 3 In the *View Configuration* window, open the **FILE** menu, and choose **PRINT**. This action opens the *Print* dialog box.
- 4 In the *Print* dialog box, choose the printer to use from the drop-down list, select printing options, and then click **OK**.

3.9 Downloading a File from PC to the Module

- 1 Use a null-modem serial cable to connected the serial COM port on your PC and the Debug/Configuration serial port on the gateway.
- 2 Open the **PROJECT** menu, and then choose **MODULE**.
- 3 On the **MODULE** menu, choose **DOWNLOAD**. Wait while ProSoft Configuration scans for communication ports on your PC. When the scan is complete, the *Download* dialog box opens.



- 4 Select the **PORT** to use for the download.
- 5 Click the **DOWNLOAD** button.

WARNING: Issues may occur when trying to download to the device's serial port. If you are experiencing similar issues, we recommend an external USB to Serial Converter.

4 Diagnostics and Troubleshooting

In This Chapter

| | |
|---|----|
| ❖ Using ProSoft Configuration Builder (PCB) for Diagnostics | 47 |
| ❖ LED Indicators..... | 51 |
| ❖ Status Data | 52 |
| ❖ Error Data | 65 |

There are two ways to troubleshoot ProLinX gateways:

- Using the LEDs located on the front of the gateway
- Using the Debug port, which provides a view into the gateway's internal database.

4.1 Using ProSoft Configuration Builder (PCB) for Diagnostics

The *Configuration and Debug* menu for this gateway is arranged as a tree structure, with the *Main* menu at the top of the tree, and one or more sub-menus for each menu command. The first menu you see when you connect to the gateway is the *Main* menu.

Because this is a text-based menu system, you enter commands by typing the [command letter] from your computer keyboard in the *Diagnostic* window in *ProSoft Configuration Builder (PCB)*. The gateway does not respond to mouse movements or clicks. The command executes as soon as you press the [COMMAND LETTER] — you do not need to press [ENTER]. When you type a [COMMAND LETTER], a new screen will be displayed in your terminal application.

4.1.1 Required Hardware

You can connect directly from your PC's serial port to the serial port on the gateway to view configuration information, perform maintenance, and send or receive configuration files.

ProSoft Technology recommends the following minimum hardware to connect your PC to the gateway:

- 80486 based processor (Pentium preferred)
- 1 megabyte of memory
- At least one UART hardware-based serial communications port available. USB-based virtual UART systems (USB to serial port adapters) often do not function reliably, especially during binary file transfers, such as when uploading/downloading configuration files or gateway firmware upgrades.

4.1.2 Using the Diagnostic Window in ProSoft Configuration Builder


Tip: You can have a ProSoft Configuration Builder Diagnostics window open for more than one module at a time.

To connect to the gateway's Configuration/Debug serial port

- 1 Start *PCB*, and then select the gateway to test. Click the right mouse button to open a shortcut menu.




- 2 On the shortcut menu, choose **DIAGNOSTICS**.




This action opens the *Diagnostics* dialog box.

- 3 Press [?] to open the *Main* menu.



If there is no response from the gateway, follow these steps:

- 1 Click to configure the connection. On the *Connection Setup* dialog box, select a valid com port or other connection type supported by the gateway.




- 2 Verify that the null modem cable is connected properly between your computer's serial port and the gateway. A regular serial cable will not work.
- 3 On computers with more than one serial port, verify that your communication program is connected to the same port that is connected to the gateway.

If you are still not able to establish a connection, contact ProSoft Technology for assistance.

4.1.3 Navigation

All of the submenus for this gateway contain commands to redisplay the menu or return to the previous menu. You can always return from a submenu to the next higher menu by pressing **[M]** on your keyboard.

The organization of the menu structure is represented in simplified form in the following illustration:



The remainder of this section shows the menus available for this gateway, and briefly discusses the commands available to you.

Keystrokes

The keyboard commands on these menus are usually not case sensitive. You can enter most commands in lowercase or uppercase letters.

The menus use a few special characters (**?**, **-**, **+**, **@**) that must be entered exactly as shown. Some of these characters will require you to use the **SHIFT**, **CTRL**, or **ALT** keys to enter them correctly. For example, on US English keyboards, enter the **?** command as **SHIFT** and **/**.

Also, take care to distinguish the different uses for uppercase letter "eye" (**I**), lowercase letter "el" (**l**), and the number one (**1**). Likewise, uppercase letter "oh" (**O**) and the number zero (**0**) are not interchangeable. Although these characters look alike on the screen, they perform different actions on the gateway and may not be used interchangeably.

4.2 LED Indicators

4.2.1 Base Module LEDs

| LED | State | Description |
|-------|-------------|---|
| Power | Off | Power is not connected to the power terminals or source is insufficient to properly power the gateway (minimum required is 800mA at 24 Vdc) |
| | Green Solid | Power is connected to the power terminals. |
| Fault | Off | Normal operation. |
| | Red Solid | A critical error has occurred. Program executable has failed or has been user-terminated and is no longer running. Press Reset p/b or cycle power to clear error. If not, use the Debug procedures described later in this manual. |
| Cfg | Off | Normal operation. |
| | Amber Solid | The unit is in configuration mode. The configuration file is currently being downloaded or, after power-up, is being read, the unit is implementing the configuration values, and initializing the hardware. This will occur during power cycle, or after pressing the reset button. It also occurs after a cold/warm boot command is received. |
| Err | Off | Normal operation. |
| | Flashing | An error condition has been detected and is occurring on one of the application ports. Check configuration and troubleshoot for communication errors. |
| | Solid Red | This error flag is cleared at the start of each command attempt (Master/Client) or on each receipt of data (slave/adaptor/server); so, if this condition exists, it indicates a large number of errors are occurring in the application (due to bad configuration) or on one or more ports (network communication failures). |

4.2.2 CC-Link Interface-Specific LEDs

| LED | State | Description |
|-------|-------|---|
| RUN | Green | Indicates CC-Link hardware is operating normally |
| | Off | Indicates a watchdog timer error/possible hardware failure |
| L RUN | Green | Indicates successful data link execution |
| L ERR | Red | Indicates a data link communication error |
| | Flash | Indicates station number or mode changing during operation |
| SD | Green | Indicates the gateway is sending CC-Link data |
| RD | Green | Indicates the gateway is receiving CC-Link data |
| ERR | Red | Indicates a switch setting error (L ERR also turns on) <ul style="list-style-type: none"> ▪ Master overlap ▪ Parameter error ▪ Communication error |

4.3 Status Data

| No. | Name | Description |
|-------------------------|---|---|
| SB0000 (REG 0 bit0) | Data link restart | Restarts the data link stopped by SB0002. OFF: No restart instruction ON: Restart |
| SB0001 (REG 0 bit1) | Refresh instruction at standby master switching | Gives a refresh instruction of cyclic data after switching to the standby master station. OFF: No instruction ON: Instruction |
| SB0002 (REG 0 bit2) | Data link stop | Stops the data link of the host. However, this function should be executed carefully since execution of this function at the master station will stop the whole system. OFF: No stop instruction ON: Stop instruction |
| SB0004 (REG 0 bit4) | Temporary error invalid request | Defines the station specified in SW0003 to SW0007 as a temporary error invalid station. OFF: No request ON: Request |
| SB0005 (REG 0 bit5) | Temporary error invalid cancel request | Cancels the station specified in SW0003 to SW0007 from a temporary error invalid station. OFF: No request ON: Request |
| SB0008 (REG 0 bit8) | Line test request | Performs a line test on the station specified in SW0008. OFF: No request ON: Request |
| SB0009 (REG 0 bit9) | Parameter setting test request | Reads the parameter information of the actual system configuration and sets it to the parameter setting test area. OFF: No request ON: Request |
| SB000C (REG 0 bit12) | Forced master switching | Forcibly shifts the master station function to the specified master station. OFF: No request ON: Request |
| SB0010 (REG 1 bit0) | Number of retries clear | Clears the number of retries. OFF: Reset not instructed ON: Reset instructed |
| SB0011 (REG 1 bit1) | Number of transmission errors clear | Clears the number of transmission errors. OFF: Reset not instructed ON: Reset instructed |
| SB0014 (REG 1 bit4) | Transient transmission clear | Clears transient transmission errors. OFF: Reset not instructed ON: Reset instructed |
| SB0015 (REG 1 bit5) | Transient transmission instruction | Prohibits transient OFF: Overwrite ON: Hold |
| SB0040 (REG 4 bit0) | Data link restart acceptance | Indicates the acceptance status of the data link restart instruction. OFF: Not accepted ON: Start instruction accepted |




| No. | Name | Description |
|-------------------------|---|---|
| SB0041 (REG 4 bit1) | Data link restart completed | Indicates the acceptance completed status of the data link restart instruction. OFF: Not completed ON: Start completed |
| SB0042 (REG 4 bit2) | Refresh instruction acceptance status at standby master switching | Indicates the acceptance status of the refresh instruction at standby master switching. OFF: Not executed ON: Instruction accepted |
| SB0043 (REG 4 bit3) | Refresh switching completed status at standby master switching | Indicates the execution completed status of the refresh switching at standby master switching. OFF: Not executed ON: Execution completed |
| SB0044 (REG 4 bit4) | Data link stop acceptance | Indicates the acceptance status of the data link stop instruction. OFF: Not accepted ON: Stop instruction accepted |
| SB0045 (REG 4 bit5) | Data link stop completed | Indicates the acceptance completed status of the data link stop instruction. OFF: Not completed ON: Stop completed |
| SB0046 (REG 4 bit6) | Forced master switching executable status | Indicates the executable status of the forced master switching (SB000C) signal. OFF: Not executable ON: Executable |
| SB0048 (REG 4 bit8) | Temporary error invalid acceptance status | Indicates the acceptance status of the temporary error invalid instruction. OFF: Not executed ON: Instruction accepted |
| SB0049 (REG 4 bit9) | Temporary error invalid completed status | Indicates the acceptance completed status of the temporary error invalid instruction. OFF: Not executed ON: Temporary error invalid station determined |
| SB004A (REG 4 bit10) | Temporary error invalid cancel acceptance status | Indicates the acceptance status of the temporary error invalid cancel instruction. OFF: Not executed ON: Instruction accepted |
| SB004B (REG 4 bit11) | Temporary error invalid cancel completed status | Indicates the acceptance completed status of the temporary error invalid cancel instruction. OFF: Not executed ON: Temporary error invalid station cancel completed |
| SB004C (REG 4 bit12) | Line test acceptance status | Indicates the acceptance status of the line test request. OFF: Not executed ON: Instruction accepted |
| SB004D (REG 4 bit13) | Line test completed status | Indicates the completed status of the line test. OFF: Not executed ON: Test completed |


| No. | Name | Description |
|-------------------------|---|---|
| SB004E (REG 4 bit14) | Parameter setting test acceptance status | Indicates the acceptance status of the parameter setting test request. OFF: Not executed ON: Instruction accepted |
| SB004F (REG 4 bit15) | Parameter setting test completed status | Indicates the completed status of the parameter setting test. OFF: Not executed ON: Test completed |
| SB0050 (REG 5 bit0) | Offline test status | Indicates the execution status of the offline test. OFF: Not executed ON: During execution |
| SB005A (REG 5 bit10) | Master switching request acceptance | Indicates the standby master station's acceptance status of the master switching request from the line. OFF: Not accepted ON: Instruction accepted (Switching request from the line accepted) |
| SB005B (REG 5 bit11) | Master switching request completed | Indicates the switching completed status of the standby master station as the master station. OFF: Not completed ON: Completed |
| SB005C (REG 5 bit12) | Forced master switching request acceptance | Indicates the acceptance status of the forced master switching request. OFF: Not accepted ON: Instruction accepted |
| SB005D (REG 5 bit13) | Forced master switching request completed | Indicates the acceptance completed status of the forced master switching request. OFF: Not completed ON: Completed |
| SB0060 (REG 6 bit0) | Host mode | Indicates the setting status of the mode setting switch of the host gateway. OFF: Online (0) ON: Other than online (0) |
| SB0061 (REG 6 bit1) | Host type | Indicates the station type of the host gateway currently operating. OFF: Master station (Station No. 0) ON: Local station, intelligent device station (Station No. 1 to 64) |
| SB0062 (REG 6 bit2) | Host standby master station setting status | Indicates whether standby master station setting has been made or not to the host. OFF: No standby master station setting to the host ON: Standby master station setting to the host |
| SB0065 (REG 6 bit5) | Input data status of host data link error station | Indicates the "data link error station's input data status" setting status of the host. OFF: Cleared ON: Retained |

| No. | Name | Description | | | | | | | | | | | | | | | |
|------------------------------------|---|---|-----------------------------|----------------------|----------------------|--------------------|-----|-----|--------------------|-----|----|--------------------|----|----|--------------------|----|-----|
| SB0066 SB0067 (REG 6 bit6,7) | Number of stations occupied by host | Indicates the setting status of the switch information 4, 5 "Number of stations occupied by host". This setting is as indicated below depending on the combination of the switch information 4, 5. <table border="1"> <thead> <tr> <th>Number of occupied stations</th> <th>Switch information 4</th> <th>Switch information 5</th> </tr> </thead> <tbody> <tr> <td>1 station occupied</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>2 station occupied</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>3 station occupied</td> <td>ON</td> <td>ON</td> </tr> <tr> <td>4 station occupied</td> <td>ON</td> <td>OFF</td> </tr> </tbody> </table> | Number of occupied stations | Switch information 4 | Switch information 5 | 1 station occupied | OFF | OFF | 2 station occupied | OFF | ON | 3 station occupied | ON | ON | 4 station occupied | ON | OFF |
| Number of occupied stations | Switch information 4 | Switch information 5 | | | | | | | | | | | | | | | |
| 1 station occupied | OFF | OFF | | | | | | | | | | | | | | | |
| 2 station occupied | OFF | ON | | | | | | | | | | | | | | | |
| 3 station occupied | ON | ON | | | | | | | | | | | | | | | |
| 4 station occupied | ON | OFF | | | | | | | | | | | | | | | |
| SB006A (REG 6 bit10) | Switch setting status | Indicates the setting status of the switches, and so on. OFF: Normal ON: Setting error (Error code stored into SW006A) | | | | | | | | | | | | | | | |
| SB006B (REG 6 bit11) | Host operation status | Indicates the operation status of the host. OFF: Normal ON: Error | | | | | | | | | | | | | | | |
| SB006C (REG 6 bit12) | Link status | Indicates the data link status of the host. OFF: During data link ON: During data link stop | | | | | | | | | | | | | | | |
| SB006D (REG 6 bit13) | Parameter setting status | Indicates the parameter setting status. OFF: Normal ON: Setting error (Error code stored into SW0068) | | | | | | | | | | | | | | | |
| SB006E (REG 6 bit14) | Host operation status | Indicates the operation status of the host data link. OFF: During execution ON: Not executed | | | | | | | | | | | | | | | |
| SB0070 (REG 7 bit0) | Master station information | Indicates the data link status. OFF: Data link by master station ON: Data link by standby master station | | | | | | | | | | | | | | | |
| SB0071 (REG 7 bit1) | Standby master station information | Whether the standby master station exists or not OFF: Does not exist ON: Exists | | | | | | | | | | | | | | | |
| SB0073 (REG 7 bit3) | Operation specification status at driver error | Indicates the parameter-based operation specification status at driver error. OFF: Stopped ON: Continued | | | | | | | | | | | | | | | |
| SB0074 (REG 7 bit4) | Reserved station specification status | Indicates the parameter-based reserved station specification status (SW0074 to SW0077) OFF: Not specified ON: Specified | | | | | | | | | | | | | | | |
| SB0075 (REG 7 bit5) | Error invalid station specification status | Indicates the parameter-based error invalid station specification status (SW0078 to SW007B) OFF: Not specified ON: Specified | | | | | | | | | | | | | | | |
| SB0076 (REG 7 bit6) | Temporary error invalid station setting information | Indicates whether the temporary error invalid stations have been set or not (SW007C to SW007F) OFF: Not set ON: Set | | | | | | | | | | | | | | | |

| No. | Name | Description |
|--------------------------|--|--|
| SB0077 (REG 7 bit7) | Parameter reception status | Indicates the parameter reception status from the master station. OFF: Reception completed ON: Reception not completed |
| SB0078 (REG 7 bit8) | Host switch change detection | Detects the setting switch change of the host during data link. OFF: No change ON: Change |
| SB0079 (REG 7 bit9) | Master station returning specification information | Indicates whether the parameter has been set to no return or a return. OFF: No return ON: Return |
| SB007B (REG 7 bit11) | Host master/standby master function operation status | Indicates whether the host is operating as the master or standby master function. OFF: Master function ON: Standby master function |
| SB0080 (REG 8 bit0) | Other station data link status | Indicates the communication status with the remote stations/local stations (SW0080 to SW0083) OFF: All stations normal ON: Error station |
| SB0081 (REG 8 bit1) | Other station watch dog timer error status | Indicates the watch dog timer error occurrence status at the other stations. OFF: No error ON: Error |
| SB0082 (REG 8 bit2) | Other station fuse blown status | Indicates the fuse blown occurrence status at other stations. OFF: No error ON: Error |
| SB0083 (REG 8 bit3) | Other station switch change status | Detects the setting switch changes of other stations during data link. OFF: No change ON: Change |
| SB0090 (REG 9 bit0) | Host line status | Indicates the line status. OFF: Normal ON: Error (Wire break) |
| SB0091 (REG 9 bit1) | Transmission status | Indicates the transmission status of the line. OFF: Normal ON: Error |
| SB0094 (REG 9 bit4) | Transient transmission status | Indicates whether a transient transmission error occurred or not. OFF: No error ON: Error |
| SB0095 (REG 9 bit5) | Master station transient transmission status | Indicates the master station transient transmission status. OFF: Normal ON: Error |
| SB00AC (REG 10 bit12) | Other station parameter status | Other station parameter communication status (SW00AC to SW00AF) OFF: Other than parameter communication in progress ON: Parameters requested |
| SB00B4 (REG 11 bit4) | Standby master station test result | The test result of Line test 1/Line test 2 is stored. OFF: Normal ON: Error |

| No. | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--------------------|---|--|----|----|----|----|----|----|----|----|----|----|--------|----|----|----|----|----|---|---|---|---|--------|----|----|----|----|----|----|----|----|----|--------|----|----|----|----|----|----|----|----|----|--------|----|----|----|----|----|----|----|----|----|
| SW0003 (REG 1) | Multiple temporary error invalid stations specification | Selects whether multiple temporary error invalid stations will be specified or not. 00: Multiple stations indicated in SW0004 to SW0007 are specified. 01 to 64: Single station 1 to 64 is specified. (For the numeral, specify the station number set as the temporary error invalid station) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0004 (REG 2) | Temporary error invalid station specification | Specifies the temporary error invalid station. 0: Not specified as the temporary error invalid station. 1: Specified as the temporary error invalid station. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0005 (REG 3) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0006 (REG 4) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0007 (REG 5) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th></th> <th>bF</th> <th>bE</th> <th>bD</th> <th>bC</th> <th></th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW0004</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW0005</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW0006</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW0007</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> 1 to 64 in the table indicates the station numbers. | | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | SW0004 | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | SW0005 | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | SW0006 | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | SW0007 | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 |
| | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0004 | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0005 | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0006 | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0007 | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0008 (REG 6) | Line-tested station setting | Sets the station on which the line test will be performed. 0: Whole system (all stations) 01 to 64: Specified station Default value: 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0041 (REG 63) | Data link restart result | The execution result of the data link restart instruction by SB0000 is stored. 0: Normal From 1 on: Error code (Refer to 4.1 Error Codes) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0043 (REG 65) | Refresh switching result at standby master switching | Indicates the execution result of refresh switching at specified standby master switching. 0: Normal Other than 0: Error code (refer to 4.1 Error Codes) is stored. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0045 (REG 67) | Data link stop result | The execution result of the data link stop instruction by SB0002 is stored. 0: Normal From 1 on: Error code (Refer to 4.1 Error Codes) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0049 (REG 71) | Temporary error invalid station specification result | Indicates the execution result of the temporary error invalid station specification. 0: Normal Other than 0: Error code (Refer to 4.1 Error Codes) is stored. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW004B (REG 73) | Temporary error invalid station specification cancel result | Indicates the execution result of the temporary error invalid station specification cancel. 0: Normal Other than 0: Error code (Refer to 4.1 Error Codes) is stored. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW004D (REG 75) | Line test result | Indicates the execution result of the line test. 0: Normal Other than 0: Error code (Refer to 4.1 Error Codes) is stored. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW004F (REG 77) | Parameter setting test request result | Indicates the execution result of the parameter setting test request by SB0009. 0: Normal Other than 0: Error code (Refer to 4.1 Error Codes) is stored. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name | Description |
|--------------------|--|---|
| SW0058 (REG 86) | Interface board status | The interface board status is stored.  |
| SW0059 (REG 87) | Transmission speed setting * | The baud rate setting is stored.  |
| SW005A (REG 88) | Built-in board switch setting status * | The switch setting of the built-in board is stored. 0: OFF 1: ON  |
| SW005D (REG 91) | Forced master switching instruction result | The execution result of the forced master switching instruction by SB000C is stored. 0: Normal From 1 on: Error code (Refer to 4.1 Error Codes) |
| SW0060 (REG 94) | Mode setting status * | The mode setting status is stored. 0: Online 2: Offline 3: Line test 1 4: Line test 2 6: Hardware test |
| SW0061 (REG 95) | Host station No. * | The currently operating host station number is stored. 0: Master station 1 to 64: Local station, intelligent device station |

| No. | Name | Description |
|---------------------|--|--|
| SW0062 (REG 96) | Operation setting status | The operation setting status is stored. 0: OFF 1: ON  |
| SW0064 (REG 98) | Number of retries information | Indicates the number of retries setting information at error response. 1 to 7 (retries) |
| SW0065 (REG 99) | Number of automatic returning stations information | Indicates the number of automatic returning stations setting information during 1 link scan. 1 to 10 (stations) |
| SW0066 (REG 100) | Delay timer information | Indicates the scan interval delay time setting information. |
| SW0067 (REG 101) | Parameter information | The parameter information area is stored. Fixed to 0: Parameter startup |
| SW0068 (REG 102) | Host parameter status | The parameter setting status is stored. 0: Normal From 1 on: Error code (Refer to 4.1 Error Code) |
| SW0069 (REG 103) | Loading status | The station number duplication and parameter consistency of each gateway are stored. 0: Normal From 1 on: Error code (Refer to 4.1 Error Code). Details are stored into SW0098-9B and SW009C-9F. |
| SW006A (REG 104) | Switch setting status | The switch setting status is stored. 0: Normal From 1 on: Error code (Refer to 4.1 Error Code) |
| SW006B (REG 105) | Host operation status | The host operation status is stored. 0: Normal 1: Transmission path error detection 2: Parameter error detection 3: CRC error detection 4: Time-out error detection 5: Abort error detection 6: Setting error detection 7: Other error detection |

| No. | Name | Description |
|---------------------|--|--|
| SW006C (REG 106) | Host data link status | The host data link status is stored. 0: Initial status 1: Parameter reception waiting status (local station only) 2: During data link 3: During data link stop 4: During disconnection (no polling request) 5: During disconnection (line error) 6: During disconnection (other) 7: During line test execution 8: During parameter setting test execution 9: During automatic return processing FF: During reset |
| SW006D (REG 107) | Maximum link scan time | The maximum value of link scan time is stored (1ms unit) |
| SW006E (REG 108) | Present link scan time | The present value of link scan time is stored (1ms unit) |
| SW006F (REG 109) | Minimum link scan time | The minimum value of link scan time is stored (1ms unit) |
| SW0070 (REG 110) | Total number of stations | The last station number set in the parameter is stored. Station 1 to 64 |
| SW0071 (REG 111) | Highest communicating station number | The highest station number (station number of the station number setting switch) that is executing data link is stored. Station 1 to 64 |
| SW0072 (REG 112) | Number of connected stations | The number of stations that are executing data link is stored. |
| SW0073 (REG 113) | Standby master station No. | The station number of the standby master station is stored. 1 to 64 (Station) |
| SW0074 (REG 114) | Reserved station specification status *1 | The reserved station setting status is stored. 0: Other than reserved station 1: Reserved station |
| SW0075 (REG 115) | | |
| SW0076 (REG 116) | | |
| SW0077 (REG 117) | | |
| | | |
| | | 1 to 64 in the table indicates the station numbers. |
| SW0078 (REG 118) | Error invalid station specification status | Indicates the temporary error invalid status. 0: Normal status 1: Temporary error invalid status |
| SW0079 (REG 119) | | |
| SW007A (REG 120) | | |
| SW007B (REG 121) | | |
| | | |
| | | 1 to 64 in the table indicates the station numbers. |
| SW007C (REG 122) | Temporary error invalid status | The error invalid station setting status is stored. 0: Other than error invalid station |

| No. | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------------|---|--|----|----|----|----|----|----|----|----|----|----|-------|----|----|----|----|----|---|---|---|---|-------|----|----|----|----|----|----|----|----|----|-------|----|----|----|----|----|----|----|----|----|-------|----|----|----|----|----|----|----|----|----|
| SW007D (REG 123) | | 1: Error invalid station | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW007E (REG 124) | | <table border="1"> <thead> <tr> <th></th> <th>bF</th> <th>bE</th> <th>bD</th> <th>bC</th> <th></th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW07C</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW07D</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW07E</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW07F</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> | | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | SW07C | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | SW07D | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | SW07E | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | SW07F | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 |
| | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW07C | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW07D | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW07E | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW07F | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 1 to 64 in the table indicates the station numbers. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0080 (REG 126) | Other station data link status | The data link status of each station is stored. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0081 (REG 127) | | 0: Normal | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0082 (REG 128) | | 1: Data link error occurrence | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0083 (REG 129) | | <table border="1"> <thead> <tr> <th></th> <th>bF</th> <th>bE</th> <th>bD</th> <th>bC</th> <th></th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW080</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW081</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW082</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW083</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> | | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | SW080 | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | SW081 | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | SW082 | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | SW083 | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 |
| | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW080 | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW081 | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW082 | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW083 | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 1 to 64 in the table indicates the station numbers. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0084 (REG 130) | Other station watch dog timer error occurrence status | Indicates the watch dog timer error occurrence status. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0085 (REG 131) | | 0: No watch dog timer error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0086 (REG 132) | | 1: Watch dog timer error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0087 (REG 133) | | <table border="1"> <thead> <tr> <th></th> <th>bF</th> <th>bE</th> <th>bD</th> <th>bC</th> <th></th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW088</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW089</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW08A</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW08B</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> | | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | SW088 | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | SW089 | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | SW08A | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | SW08B | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 |
| | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW088 | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW089 | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW08A | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW08B | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 1 to 64 in the table indicates the station numbers. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0090 (REG 142) | Line status | The line status is stored. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0: Normal | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 1: Data link disable (wire break) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0094 (REG 146) | Transient transmission status | Indicates the transient transmission error occurrence status. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0095 (REG 147) | | 0: No transient transmission error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0096 (REG 148) | | 1: Transient transmission error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0097 (REG 149) | | <table border="1"> <thead> <tr> <th></th> <th>bF</th> <th>bE</th> <th>bD</th> <th>bC</th> <th></th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW094</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW095</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW096</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW097</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> | | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | SW094 | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | SW095 | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | SW096 | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | SW097 | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 |
| | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW094 | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW095 | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW096 | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW097 | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 1 to 64 in the table indicates the station numbers. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0098 (REG 150) | Station No. duplication status | If the occupied station number of the slave station duplications with the next slave station number, the duplication status is stored. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0099 (REG 151) | | This does not apply to the case where the head station numbers duplication with each other. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW009A (REG 152) | | 0: Normal | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 1: Station number duplication (head station number only) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------------|---|---|---------|-----------|-----------------------|--------------------|----------------------------|--------------------|-----------------------|----|----|-------|-------|----|----|----|----|----|---|---|---|-------|-------|----|----|----|----|----|----|----|----|-------|-------|----|----|----|----|----|----|----|----|-------|-------|----|----|----|----|----|----|----|----|----|
| SW009B (REG 153) | | <table border="1"> <thead> <tr> <th></th> <th>bF</th> <th>bE</th> <th>bD</th> <th>bC</th> <th></th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW098</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW099</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW09A</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW09B</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> <p>1 to 64 in the table indicates the station numbers.</p> | | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | SW098 | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | SW099 | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | SW09A | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | SW09B | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 |
| | | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | SW098 | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | SW099 | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | SW09A | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW09B | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW009C (REG 154) | Loading/parameter consistency status | The consistency status, such as CC-Link version difference, between the parameters and slave stations is stored. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW009D (REG 155) | | 1) Station type inconsistency (except the combination of the following station types) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW009E (REG 156) | | <table border="1"> <thead> <tr> <th>Loading</th> <th>Parameter</th> </tr> </thead> <tbody> <tr> <td>Remote device station</td> <td>Remote I/O station</td> </tr> <tr> <td rowspan="2">Intelligent device station</td> <td>Remote I/O station</td> </tr> <tr> <td>Remote device station</td> </tr> </tbody> </table> | Loading | Parameter | Remote device station | Remote I/O station | Intelligent device station | Remote I/O station | Remote device station | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Loading | | Parameter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Remote device station | | Remote I/O station | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Intelligent device station | Remote I/O station | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Remote device station | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW009F (REG 157) | 2) Number of occupied stations inconsistency (loading > parameter) 3) Expanded cyclic setting inconsistency 4) Version inconsistency between parameter and loaded remote station | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th></th> <th>bF</th> <th>bE</th> <th>bD</th> <th>bC</th> <th></th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW09C</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW09D</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW09E</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW09F</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> <p>1 to 64 in the table indicates the station numbers.</p> | | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | SW09C | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | SW09D | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | SW09E | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | SW09F | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 | |
| | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW09C | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW09D | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW09E | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW09F | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00A0 (REG 158) | Station Type (1) | Indicates the station type of each station in bit units. 0: Remote I/O stations or remote device stations 1: Intelligent device stations | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00A1 (REG 159) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00A2 (REG 160) | | <table border="1"> <thead> <tr> <th></th> <th>bF</th> <th>bE</th> <th>bD</th> <th>bC</th> <th></th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW0A0</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>~</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW0A1</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>~</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW0A2</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>~</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW0A3</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>~</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> <p>1 to 64 in the table indicates the station numbers.</p> | | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | SW0A0 | 16 | 15 | 14 | 13 | ~ | 4 | 3 | 2 | 1 | SW0A1 | 32 | 31 | 30 | 29 | ~ | 20 | 19 | 18 | 17 | SW0A2 | 48 | 47 | 46 | 45 | ~ | 36 | 35 | 34 | 33 | SW0A3 | 64 | 63 | 62 | 61 | ~ | 52 | 51 | 50 | 49 |
| | | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0A0 | | 16 | 15 | 14 | 13 | ~ | 4 | 3 | 2 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0A1 | 32 | 31 | 30 | 29 | ~ | 20 | 19 | 18 | 17 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0A2 | 48 | 47 | 46 | 45 | ~ | 36 | 35 | 34 | 33 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0A3 | 64 | 63 | 62 | 61 | ~ | 52 | 51 | 50 | 49 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00A3 (REG 161) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00A8 (REG 166) | Station setting information | Indicates the head station of each station in bits. 0: Other than head station 1: Head station | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00A9 (REG 167) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00AA (REG 168) | | <table border="1"> <thead> <tr> <th></th> <th>bF</th> <th>bE</th> <th>bD</th> <th>bC</th> <th></th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW08C</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>~</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW08D</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>~</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW08E</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>~</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW08F</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>~</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> <p>1 to 64 in the table indicates the station numbers.</p> | | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | SW08C | 16 | 15 | 14 | 13 | ~ | 4 | 3 | 2 | 1 | SW08D | 32 | 31 | 30 | 29 | ~ | 20 | 19 | 18 | 17 | SW08E | 48 | 47 | 46 | 45 | ~ | 36 | 35 | 34 | 33 | SW08F | 64 | 63 | 62 | 61 | ~ | 52 | 51 | 50 | 49 |
| | | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW08C | | 16 | 15 | 14 | 13 | ~ | 4 | 3 | 2 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW08D | 32 | 31 | 30 | 29 | ~ | 20 | 19 | 18 | 17 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW08E | 48 | 47 | 46 | 45 | ~ | 36 | 35 | 34 | 33 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW08F | 64 | 63 | 62 | 61 | ~ | 52 | 51 | 50 | 49 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00AB (REG 169) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------------------|---|--|----|----|----|----|----|----|----|----|----|----|--------|----|----|----|----|----|---|---|---|---|--------|----|----|----|----|----|----|----|----|----|--------|----|----|----|----|----|----|----|----|----|--------|----|----|----|----|----|----|----|----|----|
| SW00AC (REG 170) | Other station parameter status | Indicates the parameter status of each station in bit units. 0: Other than communication in progress 1: Parameters requested | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00AD (REG 171) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00AE (REG 172) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00AF (REG 173) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th></th> <th>bF</th> <th>bE</th> <th>bD</th> <th>bC</th> <th></th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW0A8</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>~</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW08A9</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>~</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW0AA</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>~</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW0AB</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>~</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> | | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | SW0A8 | 16 | 15 | 14 | 13 | ~ | 4 | 3 | 2 | 1 | SW08A9 | 32 | 31 | 30 | 29 | ~ | 20 | 19 | 18 | 17 | SW0AA | 48 | 47 | 46 | 45 | ~ | 36 | 35 | 34 | 33 | SW0AB | 64 | 63 | 62 | 61 | ~ | 52 | 51 | 50 | 49 |
| | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0A8 | 16 | 15 | 14 | 13 | ~ | 4 | 3 | 2 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW08A9 | 32 | 31 | 30 | 29 | ~ | 20 | 19 | 18 | 17 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0AA | 48 | 47 | 46 | 45 | ~ | 36 | 35 | 34 | 33 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0AB | 64 | 63 | 62 | 61 | ~ | 52 | 51 | 50 | 49 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 1 to 64 in the table indicates the station numbers. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00B4 (REG 178) | Line test 1 result | The test result of Line test 1 is stored. 0: Normal 1: Error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00B5 (REG 179) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00B6 (REG 180) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00B7 (REG 181) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th></th> <th>bF</th> <th>bE</th> <th>bD</th> <th>bC</th> <th></th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW0B4</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW0B5</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW0B6</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW0B7</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> | | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | SW0B4 | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | SW0B5 | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | SW0B6 | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | SW0B7 | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 |
| | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0B4 | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0B5 | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0B6 | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0B7 | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 1 to 64 in the table indicates the station numbers. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00B8 (REG 182) | Line test result | Stores the line test result. 0: Normal Other than 0: Error code (See Section 4.1, "Error Codes.") | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00C0 (REG 190) | Retry count | Stores the retry execution count. 0 or more: Accumulated retry count | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00E1 (REG 203) | Transient transmission error count | Stores the number of errors that occurred during transient transmission. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00E2 (REG 204) | Transient transmission error data pointer | Stores the next pointer for setting the transient transmission error code. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW00E3 (REG 205) | Transient transmission error code | Stores the error code that occurred during transient transmission (29 areas) Storage method: Ring buffer | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| To SW00FF (REG 253) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0140 (REG 318) | Station type (2) | Indicates whether the remote station is Ver. 2 compatible. 0: Ver. 1 compatible remote station. 1: Ver. 2 compatible remote station | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW141 (REG 319) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW142 (REG 320) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0143 (REG 321) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th></th> <th>bF</th> <th>bE</th> <th>bD</th> <th>bC</th> <th></th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW0140</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW0141</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW0142</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW0143</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> | | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | SW0140 | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | SW0141 | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | SW0142 | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | SW0143 | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 |
| | bF | bE | bD | bC | | b3 | b2 | b1 | b0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0140 | 16 | 15 | 14 | 13 | to | 4 | 3 | 2 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0141 | 32 | 31 | 30 | 29 | to | 20 | 19 | 18 | 17 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0142 | 48 | 47 | 46 | 45 | to | 36 | 35 | 34 | 33 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0143 | 64 | 63 | 62 | 61 | to | 52 | 51 | 50 | 49 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 1 to 64 in the table indicates the station numbers. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW0144 (REG 322) | Mounting/Parameter consistency status (2) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name | Description |
|---|---------------------|--|
| SW0145 (REG 323) | | |
| | | SW0144 |
| | | SW0145 |
| | | SW0146 |
| SW0146 (REG 324) | | SW0145 |
| | | SW0146 |
| SW0147 (REG 325) | | SW0147 |
| | | SW0147 |
| 1 to 64 in the table indicates the station numbers. | | |
| SW148 (REG 326) | Parameter mode | Indicates the mode used in the network. 0: Ver. 1 mode 2: Ver. 2 mode |
| SW149 (REG 327) | Host parameter mode | Indicates the mode in which the host station is operating. 0: Ver. 1 mode 2: Ver. 2 mode |

4.4 Error Data

| Error Code (Hexadecimal) | Error | Error Cause (Details) | Corrective Action | Detectability | |
|-----------------------------|---|--|--|----------------|---|
| | | | | Master Station | Local Station or Intelligent Device Station |
| B002 | Link stop error | Link stop was implemented when the link was already stopped. | Change the interface board. | Y | N |
| B102 | Link error | A line error has occurred. | Check the interface board. | Y | Y |
| B103 | Setting value error | The setting value of the macro function is invalid. | Change the interface board. | Y | N |
| B104 | Start error | Link startup was implemented when the link was already started. | Change the interface board. | Y | N |
| B105 | Stop error | Link stop was implemented when the link was already stopped. | Change the interface board. | Y | N |
| B110 | Unable to receive transient data | A line error has occurred. | Check the line. | Y | Y |
| B111 | Transient data receiving order error | A line error has occurred. | Check the line. | Y | Y |
| B112 | Transient data length error | A line error has occurred. | Check the line. | Y | Y |
| B113 | Transient data ID error | A line error has occurred. | Check the line. | Y | Y |
| B115 | Link error | A line error has occurred. | Check the line. | Y | Y |
| B201 | Relevant station error when sending | A data link error has occurred at the relevant station at the time of transient transmission. | Check the status of communication with other stations, whether or not a temporary error invalid station is specified, or if the host station is stopped. | Y | Y |
| B202 | Data length error | A line error may have occurred if improper packet data length is identified at the time of transient transmission. | Check the line. Set a data length that fulfills required conditions. | Y | Y |
| B203 | CT value error | The CT value in the CC-Link transient frame is wrong. | Check the value in the CC-Link transient frame. | Y | Y |
| B204 | Failed to ensure error response send buffer | The buffer area could not be ensured at the time of error response transmission. | Wait a while and then retransmit (Transient operation overload status) | Y | Y |

| Error Code (Hexadecimal) | Error | Error Cause (Details) | Corrective Action | Detectability | |
|-----------------------------|---|---|---|-------------------|---|
| | | | | Master Station | Local Station or Intelligent Device Station |
| B205 | Target station is not intelligent device station | The target station was not an intelligent device station. | Check the target station. | Y | Y |
| B301 | Unable to request processing due to link stop | A line test request was issued while the data link is stopped. | Perform a line test while the data link is being established. | Y | Y |
| B302 | Specified station number exceeds the highest allowable station number | The station number specified for a temporary error invalid request or temporary error invalid cancel request exceeded the highest allowable station number. | Specify a station number that is not greater than the highest allowable station number. | Y | N |
| B303 | No station number specified | No station number is specified for a temporary error invalid request or cancel request. | Specify any station numbers (SW0003, SW0004 to SW0007) | Y | N |
| B304 | Error station detected by line test (reception status error) | An error was detected in a slave station during line test execution. | Check that the slave station is operational and that the cable is not disconnected. | Y | N |
| B305 | Error station detected by line test (response data error) | An error was detected in the response data looped back as a result of line test execution. | Replace the slave station subjected to the line test. | Y | N |
| B306 | Specified station is not head station | A station other than the head station was specified for the temporary error invalid request. | Specify a head station for the temporary error invalid request. | Y | N |
| B307 | All stations faulty | All stations were in a data link error state when either of the following requests was issued: SB0000 (data link restart) SB0002 (data link stop) | Request again after the data link becomes normal. | Y | Y |
| B308 | Total number of slave stations (station number error) | The station number is outside the range 1 to 64. | Check the station numbers of the mounted gateways for any duplication (including occupied station numbers). | Y | N |

| Error Code (Hexadecimal) | Error | Error Cause (Details) | Corrective Action | Detectability | | | | | | | | |
|-----------------------------|---|---|---|-------------------|---|------------|--------------------|------------|---------------|-------------------------|---|---|
| | | | | Master Station | Local Station or Intelligent Device Station | | | | | | | |
| B309 | Station number duplication | The station number of the connected gateway was duplicated (including occupied station numbers). Note that this excludes duplication of the head station number. | Check the gateways' station numbers. | Y | N | | | | | | | |
| | Inconsistency between connected gateway and parameter (connected gateway > parameter) | The station types of the gateway are different from those set as parameters, or the number of occupied stations of the gateway is greater than the parameter. Example: <table border="1" style="margin-left: 20px;"> <tr> <td>Connected gateway</td> <td>Parameter Setting</td> </tr> <tr> <td>Remote device</td> <td>Remote I/O</td> </tr> <tr> <td rowspan="2">Intelligent device</td> <td>Remote I/O</td> </tr> <tr> <td>Remote device</td> </tr> </table> | Connected gateway | Parameter Setting | Remote device | Remote I/O | Intelligent device | Remote I/O | Remote device | Set correct parameters. | Y | N |
| Connected gateway | Parameter Setting | | | | | | | | | | | |
| Remote device | Remote I/O | | | | | | | | | | | |
| Intelligent device | Remote I/O | | | | | | | | | | | |
| | Remote device | | | | | | | | | | | |
| B30B | Inconsistency between connected gateway and parameter | The mounting state does not match the corresponding parameters (A station, whose station number is set as a parameter, is not mounted) | Match the mounting status with corresponding parameters. | Y | N | | | | | | | |
| B30C | Switching station specification error | SB0001 was turned ON in other than the master station or a system that does not have a standby master station. | Check if the standby master station exists in the system. | Y | Y | | | | | | | |
| B30D | Initial status | Temporary error invalid station specification and SB requests were issued before starting the data link. | Issue the requests after the data link is started. | Y | N | | | | | | | |
| B30E | Local station not supported | The execution of the function, which is started by SB/SW and executable at the master station only, was attempted at the local station. | Execute the function from the master station. | N | Y | | | | | | | |
| B310 | Data link restart error | A data link restart request (SB0000) was executed for the station that was performing a data link. | Execute the data link restart request (SB0000) for the station that has stopped a data link with a data link stop request (SB0002). | Y | Y | | | | | | | |

| Error Code (Hexadecimal) | Error | Error Cause (Details) | Corrective Action | Detectability | |
|-----------------------------|---|---|---|-------------------|---|
| | | | | Master Station | Local Station or Intelligent Device Station |
| B311 | Data link stop error | A data link stop request (SB0002) was executed for the station that had stopped a data link. | Execute the data link stop request (SB0002) for the station that is performing a data link. | Y | Y |
| B312 | Standby master station absence error | A forced master to standby master switching request (SB000C) was issued in a system where no standby master station exists or where the standby master station had become faulty. | Execute the request after starting the data link of the standby master station. | Y | N |
| B313 | All stations faulty | A forced master to standby master switching request (SB000C) was issued in a system where all stations had become faulty. | Execute the request after starting the data link of the standby master station. | Y | N |
| B314 | Switching target error | A forced master to standby master switching request (SB000C) was issued to a station other than the master station. | Execute the request to the master station. | N | Y |
| B315 | Forced switching error during master switching | A forced master to standby master switching request (SB000C) was issued again while the master station was being switched to the standby master station. | Check the ON/OFF operation of SB000C. | Y | N |
| B384 | Station number setting error (parameter) | The station number (including the occupied station numbers) of the station information parameter was set to a value outside the range 1H to 40H. | Set a value within the range 1H to 40H. | Y | N |
| B385 | Total number of slave stations error (total number of occupied stations > 64) | The total number of occupied stations set in the station information parameter exceeded 64. | Set a parameter value of 64 or less. | Y | N |
| B386 | Total number of slave stations (all stations reserved specification) | All the numbers of occupied stations were set to 0 in the station information parameter. | Set each of the occupied station numbers to a value within the range 1 to 4. | Y | N |
| B387 | Delay timer setting error | The delay timer was set to a value outside the range 0 to 100. | Set the delay timer to a value within the range 0 to 100. | Y | Y |

| Error Code (Hexadecimal) | Error | Error Cause (Details) | Corrective Action | Detectability | |
|-----------------------------|--|---|---|-------------------|---|
| | | | | Master Station | Local Station or Intelligent Device Station |
| B388 | Station information specification (other than 0 to 3) | The station type in the station information parameter was set to a value other than 0 to 3 (Ver. 1 mode only) | Set the station type to a value within the range 0 to 3. | Y | N |
| B38A | Station information specification (number of remote I/O stations > 64) | The number of remote I/O stations was set to a value of 65 or more with the station information parameter. | Set the number of remote I/O stations to a value of 64 or less. | Y | N |
| B38B | Station information specification (number of remote device stations > 42) | The number of remote device stations was set to a value of 43 or more with the station information parameter (addresses 0440H to 04BEH). | Set the number of remote device stations to a value of 42 or less. | Y | N |
| B38C | Station information specification (number of intelligent device stations > 26) | The number of intelligent device stations (including local stations) was set to a value of 27 or more with the station information parameter. | Set the number of intelligent device stations to a value of 26 or less. | Y | N |
| B38E | Buffer assignment specification (transfer data size > 4k words) | The total size of the transfer buffers in the station information parameter exceeded 4k words. | Set the total size of the transfer buffers to less than 4k words. | Y | Y |
| B38F | Buffer assignment specification (unused area) | Writing was performed to a use prohibited (unused) area of the dual port RAM. | Do not write to the use prohibited (unused) area of the dual port RAM. | Y | Y |
| B390 | Standby master station specification (station number error) | The standby master station specification parameter was set to a value outside the range of 0 to 64. | Specify the standby master station number to a value within the range of 0 to 64. | Y | Y |
| B391 | Retry count (other than 1 to 7) | The retry count parameter was set to a value outside the range of 1 to 7. | Set a value within the range of 1 to 7. | Y | N |
| B392 | Specification in the event of a driver error (other than 0 and 1) | The parameter specifying the operation in the event of a driver error was set to a value other than 0 and 1. | Set 0 or 1. | Y | N |

| Error Code (Hexadecimal) | Error | Error Cause (Details) | Corrective Action | Detectability | |
|-----------------------------|---|---|--|-------------------|---|
| | | | | Master Station | Local Station or Intelligent Device Station |
| B394 | Invalid number of automatic return stations (parameter) | The "number of automatic return stations" parameter was set to a value outside the range of 1 to 10. | Set a value within the range of 1 to 10. | Y | N |
| B396 | Duplicate station number error (parameter) | A duplicate station number was specified with the station information parameter. | Set parameters correctly so that no station numbers are duplicated. | Y | N |
| B397 | Station information setting error (parameter) | The station information parameter setting does not meet the following condition: $(16 \times A) + (54 \times B) + (88 \times C) \leq 2304$ A: Number of remote I/O stations B: Number of remote device stations C: Number of intelligent device stations (including local stations) | Set the parameter so that it meets the condition shown on the left. | Y | N |
| B398 | Invalid number of occupied stations (parameter) | The number of occupied stations in the station information parameter (addresses 0220H to 025F) was set to a value outside the range of 1 to 4. | Set a value within the range from 1 to 4. | Y | N |
| B399 | Invalid number of connected gateways (parameter) | The "number of connected gateways" parameter was set to a value outside the range of 1 to 64. | Set a value within the range of 1 to 64. | Y | N |
| B39A | Standby master station specification (different from host station number) | The "standby master station number" set to the master station is different from the actual station number of the standby master station, or it is a local station number. | Change the parameter setting of the master station, or change the station number setting of the local/standby master station, and then reset the system. | N | Y |
| B39B | All stations reserved setting | All stations were set as reserved stations. | Check the reserved station settings. | Y | N |

| Error Code (Hexadecimal) | Error | Error Cause (Details) | Corrective Action | Detectability | |
|-----------------------------|--|--|--|----------------|---|
| | | | | Master Station | Local Station or Intelligent Device Station |
| B39C | Station type when standby master station is specified Ver. 1 mode: Other than 2 and 3 Ver. 2 mode: Other than 6, 9, C and F | Any other than "intelligent device station" is set in the station type in the slave station setting of the station set as the standby master station. Or, the mode of the master station is different from the one set in the standby master station specification. | Specify the standby master station as an intelligent device station. | Y | N |
| B39E | 8-/16-point setting illegal | A setting of 8-point I/O station or 16-point I/O station has been made for a station other than the remote I/O station. | Configure an 8-point/16-point setting for the remote I/O station. | Y | N |
| B3A0 | Mode illegal (master/local stations) | A model illegal error has occurred between the master and the local or standby master station. The mode differs between the master and standby master stations. The local station is in the Ver. 2/additional mode while the master station is in the Ver. 1 mode. | After setting the master station parameter or local or standby master station parameter again, reset the system. | N | Y |
| B3A1 | Standby master setting illegal | An illegal value has been set in the standby master station information of switch information 5. | Set a correct value in the standby master station information of switch information 5. | Y | N |
| B3A3 | Assignment error | The assignment of RX, RY, RWw or RWr exceeds the maximum number of points, or the total number of RX/Ry points in the station information parameter exceeds 8192 in Ver. 2 mode. | Change the station information, decreasing the numbers of RX, RY, RWw and RWr points. | Y | N |
| B3A4 | Parameter mismatch | A mismatch occurred between the master station parameter and standby master station parameter when using the master station duplex function. | Return the master station parameter to the original value. | Y | N |
| B601 | Command type setting error | A nonexistent command type was set. | Set a correct command type. | Y | Y |
| B602 | Send buffer acquisition failed | The send buffer could not be obtained. | Wait a while and then transmit (Transient operation overload status) | Y | Y |

| Error Code (Hexadecimal) | Error | Error Cause (Details) | Corrective Action | Detectability | |
|-----------------------------|--|---|--|-------------------|---|
| | | | | Master Station | Local Station or Intelligent Device Station |
| B603 | Send buffer acquisition failed | The send buffer could not be obtained. | Wait a while and then transmit (Transient operation overload status) | Y | Y |
| B604 | Line test in progress | Transient transmission was attempted when a line test was in progress. | Wait a while and then retransmit. | Y | N |
| B605 | Unable to access transient buffer | The transient buffer could not be obtained. | Wait a while and then retransmit. | Y | Y |
| B606 | Unable to access system information | The system information could not be obtained. | With the current system, "unable to access system information" is inconceivable. | Y | Y |
| B60C | Faulty station detected with line test (response data error) | An error was detected in response data as the result of line test execution. | Replace the slave station subjected to the line test. | Y | N |
| B771 | Transient request overload error | There are too many transient requests to the station. | Wait a while and then retransmit (Transient operation overload status) | Y | Y |
| B772 | Send buffer awaiting data exceeded maximum | The number of data awaiting transient send buffer acquisition exceeded the maximum. | Wait a while and then retransmit (Transient operation overload status) | Y | Y |
| B773 | Receive buffer awaiting data exceeded maximum | The number of data awaiting transient receive buffer acquisition exceeded the maximum. | Wait a while and then retransmit (Transient operation overload status). | Y | Y |
| B774 | Target station not intelligent device | The target station is not an intelligent device station. | Check if the target station is an intelligent device station. | Y | Y |
| B778 | Response timeout | No response was received from the requested station. | Check the requested gateway and cables. | Y | Y |
| B781 | Faulty response data reception | Faulty response data was received. | Check the cable, and so on. | Y | Y |
| B782 | Station number specification error | The transmission destination station and transmission source station were the same when other station connection was specified. | Check the station number of the transmission destination. Or, change the setting to host station connection. | Y | Y |

| Error Code (Hexadecimal) | Error | Error Cause (Details) | Corrective Action | Detectability | |
|-----------------------------|--|---|---|----------------|---|
| | | | | Master Station | Local Station or Intelligent Device Station |
| B783 | Transient storage buffer error | An error occurred in the transient storage buffer at the time of transient transmission exceeding 1K. | Wait a while and transmit the data once again. Check the cable, and so on. | Y | Y |
| B801 | Access code setting error | A nonexistent access code/property was set. | Set a correct command type. | Y | Y |
| B802 | Access code error | A nonexistent access code was used. | Use a correct access code. | Y | Y |
| B803 | Data points error | The number of data points is out of range. | Set the number of data points to a value within the range of 1 to 960 bytes. | Y | Y |
| B804 | Attribute definition error Transient transmission unsupported station specification error | The attribute definition is invalid. Or, transient transmission was performed even though the target station does not support transient transmission. | Review the attribute definition. Check the specification of the target station number. | Y | Y |
| B805 | Data amount error | The data amount is out of range. | Set it to a value within the range of 1 to 100 for writing, and within the range of 1 to 160 for reading. | Y | Y |
| B807 | Address definition error | The address number is not a multiple of 16 when accessing a bit device. | Set a multiple of 16 to the address number when accessing the bit device. | Y | Y |
| B80A | Data length error | The data length is abnormal. | Check the data length. | Y | Y |
| B80D | (Addresses and points) range error | The specified combination (addresses and points) exceeded the valid processing range. | Make the setting so that the number of processing points does not exceed the device range. | Y | Y |
| B812 | Total number of points exceeded 960 bytes at time of transient transmission | The total number of points exceeded 960 bytes at the time of transient transmission. | Set 960 bytes or less to the number of points. | Y | Y |
| B823 | Remote control mode error | The mode specification for the remote control is incorrect. | Check the mode specification. | Y | Y |
| B903 | No parameter | A transient request was issued to a station for which no transfer buffer area is ensured. | Ensure a transfer buffer area with a parameter. | Y | Y |

| Error Code (Hexadecimal) | Error | Error Cause (Details) | Corrective Action | Detectability | |
|-----------------------------|---|---|--|----------------|---|
| | | | | Master Station | Local Station or Intelligent Device Station |
| B904 | Buffer size error | When the dedicated instruction is executed, the transfer buffer size setting of the station is outside the setting range. | Set the transfer buffer size of the station within the setting range. | Y | Y |
| B9FE | Parameter sumcheck error | The sumcheck value of the parameter setting area is abnormal. | Check the sumcheck value. | Y | N |
| B9FF | Software handshake error | An alive check error is detected in handshake processing with the driver. | Replace the interface board. | Y | Y |
| BA19 | Relevant station error | The station that is being tested stopped communication during the line test. | Check the cable and the relevant station. | Y | N |
| BA1B | All stations error | A communication error occurred at all stations during line test 1. | Check the cables. | Y | N |
| BBC1 | Mode number switch error | The mode switch setting is outside the setting range. | Check the mode. | Y | Y |
| BBC5 | Master station duplication error | The master station already exists. Alternatively, line noise was detected at power on. | Reduce the number of master stations on the same line to one. Or, check the line status. | Y | N |
| BBC7 | MFP/Hardware error detected | The MFP chip state does not change to the ready state. | Replace the user circuit board. | Y | Y |
| BD87 | User circuit board error detected | A WDT error occurred for NMI. | Replace the user circuit board. | Y | Y |
| BF01 | Send buffer storage location error | Data was set in a send buffer not assigned by the value set for DA. | Check the transfer buffer assignments and DA value. | Y | N |
| BF02 | Transfer buffer size error | The transfer buffer size was not enough to store the header information. | Check the transfer buffer size. | Y | Y |
| BF03 | Data size exceeded | The amount of transferred data exceeded the communication buffer size. | Check the transfer buffer size. | Y | Y |
| BF04 | Transient transmission target station error | Transient transmission was conducted with a station for which no setting was made or a station that is not an intelligent device station. | Check the parameter setting. | Y | N |
| BF10 | Response transmission failed | There is no reception data, or no response waiting. | Transmit the response after receiving a request. Check the value of SW000A. | Y | Y |

5 Reference

In This Chapter

| | |
|---|----|
| ❖ General Overview | 76 |
| ❖ CC-Link Overview | 77 |
| ❖ ProLinX CCLINK User Data Memory..... | 79 |
| ❖ CC-Link Cyclic Data Concepts | 85 |
| ❖ CC-Link Transient Data Messaging Concepts | 88 |
| ❖ Specifications | 90 |
| ❖ RS-232 Configuration/Debug Port..... | 93 |
| ❖ DB9 to Mini-DIN Adaptor (Cable 09) | 94 |
| ❖ CC-Link Port..... | 95 |

5.1 General Overview

All ProLinX® stand-alone communications gateways allow for data transfer between diverse systems, using two normally incompatible communications protocols. ProLinX gateways accomplish this data transfer by storing data in internal 16-bit memory registers. Data can be written into the ProLinX gateway and stored into its memory by either of the two protocols. After data is stored in the gateway's memory; it is then available to be read or written by either of the two protocols, thus allowing data to be passed between devices, controllers, or processors using different protocols.

The physical network interfaces supported by any ProLinX gateway depend on the application protocols installed on it. Some have only serial communications ports for serial-based protocols, some have an Ethernet port for Ethernet-based protocols, and some have both an Ethernet port and one or more serial ports to support passing data between serial-based and Ethernet-based protocols.

The ProSoft Technology® ProLinX CCLINK protocol solution is a Local Station (slave-only, cannot be a back-up Master Station) or Intelligent Device implementation of the CC-Link Partner Association (CLPA) "CC-Link" high-speed serial protocol. The ProLinX CCLINK protocol driver supports the CC-Link protocol specification version 1.10 and allows the gateway to act as a CC-Link slave on your CC-Link high-speed serial communication and control network.

In this document, whenever you see "CCLINK", this refers to the ProLinX CCLINK protocol driver implementation. Whenever you see "CC-Link", this refers to the protocol in general or to the protocol implementation on the Mitsubishi PLC system. These difference references allow an easy way to identify exactly which CCLINK/CC-Link protocol implementation is being discussed at that point in this document.

5.2 CC-Link Overview

5.2.1 Types of CC-Link Data Transfers

The CC-Link protocol allows for two major ways to transfer process data, Cyclic Data transmission and Transient Message transmission. Cyclic Data transmission involves the movement of specific amounts of binary and register input and output data to and from the Master Station and all Slave stations on the network at a regular interval and in a continuously repeating 'cycle'. Such Cyclic Data transmission is 'automatic' and happens under the control of the CC-Link network Master.

Transient Messages allow for data to be transmitted on the network in variable amounts, at irregular intervals, based on specific logical events or register values, and are controlled by the Master Station, Local Station, or Intelligent Device that initiates the message. Transient Messages allow for the movement of data that might not otherwise be available in normal Master-Slave Cyclic Data transfers. Not all CC-Link Slave devices are capable of generating or responding to Transient Messages; but certain types of Transient Messages are supported in the ProLinx CCLINK protocol driver (more on this later)

In the ProLinx CCLINK implementation, separate internal memory database areas have been reserved to hold specific types of CC-Link Cyclic Data, as well as a large database area for holding Transient Message Data.

The Cyclic Data transfer portion of the CC-Link protocol is a Master-Slave type implementation. That is, there will be one Master Station on the CC-Link network that controls all the Cyclic Data transmission on the network between itself and one or more Slave Stations, which respond to cyclic messages from the Master.

The protocol allows additional data transfer capability by using Transient Messages for data transmission. Transient Message transfers operate in more of a peer-to-peer implementation, in that any Transient Message-capable Station on the network can initiate and respond to Transient Messages from any other Station on the network.

5.2.2 Types of CC-Link Slave Stations

A distinction needs to be made between physical slave devices and logical Slave Stations. A CC-Link network can have a maximum of 64 logical Slave Stations, each with a unique Station Number. Each logical station will be allowed to exchange a fixed amount of each type of Cyclic Data with the CC-Link Master:

- 32 bits of data to be read by the Master Station from the Slave Station
- 32-bits of data to be written by the Master Station to the Slave Station
- Four, 16-bit integer words of data to be read by the Master Station from the Slave Station
- Four, 16-bit words of data to be written by the Master Station to the Slave Station

There are some physical slave devices that have more data than can fit within these rigid logical station limits. The CC-Link protocol allows users to overcome these logical station limits by allowing certain physical slave devices to be configured as one, two, three, or four logical stations, with consecutive logical Station Addresses. Doing so allows one physical slave device to pass a total amount of Cyclic Data equal to the amount allowed for up to four logical stations.

The CC-Link protocol allows for three different types of slave stations:

- Remote I/O Stations - Cyclic binary bit data transfer only, no Transient Messaging, may occupy only one logical station address
- Intelligent Device Stations - Cyclic and Transient data transfers, may occupy up to four logical station addresses
- Local Stations - Cyclic and Transient data transfers, may occupy up to four logical station addresses, will receive a copy of all Slave Station Cyclic and Status data from the network Master and store that data internally

Remote I/O Stations are the simplest form of slave station and are not supported in the ProLinx CCLINK driver because of that type's severely limited data transfer capability. Intelligent Device Stations and Local Stations provide greater data transfer flexibility and are supported in the CCLINK driver.

The CC-Link protocol allows some Local Stations to be set up as CC-Link Standby Master Stations; however, the ProLinx CCLINK driver is currently a slave-only implementation, so the ProLinx gateway cannot be configured as a CC-Link Standby Master.

5.3 ProLinx CCLINK User Data Memory

5.3.1 ProLinx CCLINK Memory Map Overview

Whether the ProLinx gateway is configured as an Intelligent Station or as a Local Station, it will have a memory area in the gateway's CCLINK database to store its own RX, RWr, RY, and RWw data. If the gateway is configured to be an Intelligent Station, its CCLINK database will contain only its own RX, RWr, RY, and RWw data. If the gateway is configured to be a Local Station, its CCLINK database will contain not only its own RX, RWr, RY, and RWw data areas but also a copy of the RX, RWr, RY, and RWw data from all the slaves on the CC-Link network. This data will be contained in a special area called the "Network Data Area." When the gateway is configured as an Intelligent Station, this data area is reserved and not used by the CCLINK protocol driver.

The ProLinx gateway has 10,000, 16-bit memory storage registers available for storing user data. This data can then be passed between devices on the CC-Link network and whatever other network protocol has been provided on the gateway. The other protocol driver may have access to all 10,000 registers and may be able to read from or write to any of these memory locations. However, to preserve CC-Link protocol data partitioning, the ProLinx CCLINK protocol driver will allow access to the ProLinx memory database only as specified in the following table.

The CCLINK driver has specific memory areas assigned for each CC-Link data type with gaps built in between each area to maintain data separation and allow the different CC-Link data areas to start on easily-remembered ProLinx user database memory addresses. These addresses are spaced out to start at some even multiple of ten, as follows:

- **RX** data area starts at ProLinx memory database register address 0
- **RW_r** data starts at address 10
- **RY** data starts at address 30
- **RW_w** data starts at address 40
- **SB** status data starts at address 60
- **SW** status data starts at address 100
- **Network data** (for a Local Station) or the Reserved area (for an Intelligent Device Station) starts at address 500
- **Transient** Message data starts at address 1300.

You will notice in the following chart that there are some memory registers between the CCLINK data areas that are not used by the CCLINK protocol driver. These addresses are not accessible to the CC-Link Master. The memory registers in the gaps between these data areas are usually (but not always) accessible by the other installed protocol driver but should not be used to hold user data for your application, since they cannot be accessed by the CCLINK protocol driver.

The following table describes the ProLinx memory layouts for an Intelligent Station and for a Local Station.

| Intelligent Device Station | | | Local Station | | |
|----------------------------|--|-------------|---------------|---|-------------|
| Word Address | Layout Description | Word Length | Word Address | Layout Description | Word Length |
| 0000 | CCLINK RX bit data area 32 bits per station | 8 | 0000 | CCLINK RX bit data area 32 bits per station | 8 |
| 0007 | | | 0007 | | |
| 0010 | CCLINK RWr word data area 4 words per station | 16 | 0010 | CCLINK RWr word data area 4 words per station | 16 |
| 0025 | | | 0025 | | |
| 0030 | CCLINK RY bit data area 32 bits per station | 8 | 0030 | CCLINK RY bit data are 32 bits per station | 8 |
| 0037 | | | 0037 | | |
| 0040 | CCLINK RWw word data area 4 words per station | 16 | 0040 | CCLINK RWw word data area 4 words per station | 16 |
| 0055 | | | 0055 | | |
| 0060 | CCLINK SB Link Special Relay data area | 12 | 0060 | CCLINK SB Link Special Relay data area | 12 |
| 0071 | | | 0071 | | |
| 0100 | CCLINK SW Special Register data area | 378 | 0100 | CCLINK SW Special Register data area | 378 |
| 0477 | | | 0477 | | |
| 0500 | This is reserved to hold Network data when the ProLinX is configured as a Local Station. It is not used by the CCLINK driver when the ProLinX is configured as an Intelligent Station; but may be used by the DFNT driver. 786 words | 786 | 0500 | Network RX Data area 2048 bits | 128 |
| | | | 0627 | | |
| | | | 0630 | Network RWr Data area 256 words | 256 |
| | | | 885 | | |
| | | | 0900 | Network RY Data area 2048 bits | 128 |
| | | | 1027 | | |
| | | | 1030 | Network RWw Data area 256 words | 256 |
| | | | 1285 | | |
| | | | 1300 | | |
| | | | 9999 | | |
| 1285 | | | 1285 | | |
| 1300 | CC-Link Transient Message Data and extra DFNT data area 8700 words | 8700 | 1300 | CC-Link Transient Message Data and extra DFNT data area 8700 words | 8700 |
| 9999 | | | 9999 | | |

5.3.2 ProLinX CCLINK Memory Area Breakdown by Logical Station

As mentioned before, the ProLinX gateway can be configured as one, two, three or four logical stations. Therefore, the RX, RWr, RY, and RWw data areas had to be sized to hold enough data for four logical stations. The following table shows where data for each logical station can be found in each data type area. This same data mapping is used whether the ProLinX CCLINK driver is configured as an Intelligent Station or as a Local Station.

| ProLinX Word Address | CCLINK RX Memory by Logical Station | RX Words Used per Station | Total RX Words Used |
|----------------------|--------------------------------------|----------------------------|----------------------|
| 0000 | First Logical Station | 2 registers | 2 registers |
| 0001 | | | |
| 0002 | Second Logical Station | 2 registers | 4 registers |
| 0003 | | | |
| 0004 | Third Logical Station | 2 registers | 6 registers |
| 0005 | | | |
| 0006 | Fourth Logical Station | 2 registers | 8 registers |
| 0007 | | | |
| ProLinX Word Address | CCLINK RWr Memory By Logical Station | RWr Words Used per Station | Total RWr Words Used |
| 0010 | First Logical Station | 4 registers | 4 registers |
| 0013 | | | |
| 0014 | Second Logical Station | 4 registers | 8 registers |
| 0017 | | | |
| 0018 | Third Logical Station | 4 registers | 12 registers |
| 0021 | | | |
| 0022 | Fourth Logical Station | 4 registers | 16 registers |
| 0025 | | | |
| ProLinX Word Address | CCLINK RY Memory By Logical Station | RY Words Used per Station | Total RY Words Used |
| 0030 | First Logical Station | 2 registers | 2 registers |
| 0031 | | | |
| 0032 | Second Logical Station | 2 registers | 4 registers |
| 0033 | | | |
| 0034 | Third Logical Station | 2 registers | 6 registers |
| 0035 | | | |
| 0036 | Fourth Logical Station | 2 registers | 8 registers |
| 0037 | | | |

| ProLinx Word Address | CCLINK RWw Memory By Logical Station | RWw Words Used per Station | Total RWw Words Used |
|----------------------|--------------------------------------|----------------------------|----------------------|
| 0040 | First Logical Station | 4 registers | 4 registers |
| 0043 | | | |
| 0044 | Second Logical Station | 4 registers | 8 registers |
| 0047 | | | |
| 0048 | Third Logical Station | 4 registers | 12 registers |
| 0051 | | | |
| 0052 | Fourth Logical Station | 4 registers | 16 registers |
| 0055 | | | |

5.3.3 ProLinx Local Station Network Data Area Breakdown

When the ProLinx CCLINK driver is configured as a Local Station, it will receive a copy of the RX, RWw, RY, and RWw data from every slave on the CC-Link network, including its own data. This data copy is stored in a Network Data area, as shown in the ProLinx CCLINK Memory Map Overview. The following chart shows how this Network Data area is broken down by data type and Logical Station Number. You will notice that, once again, the data is grouped into blocks of memory based on the CC-Link data type.

| ProLinx Word Address | CCLINK Network RX Data Memory by Logical Station Number | Network RX Words Used per Station |
|----------------------|---|-----------------------------------|
| 0500 | Logical Station Number 1 | 2 registers |
| 0501 | | |
| 0502 | Logical Station Number 2 | 2 registers |
| 0503 | | |
| 0504 | Logical Station Number 3 | 2 registers |
| 0505 | | |
| 0506 | Logical Station Number 4 | 2 registers |
| 0507 | | |
| 0508 | Logical Station Number 5 to Logical Station Number 63 | 2 registers per Logical Station |
| 625 | | |
| 0626 | | |
| 0627 | | |
| | | |
| | | |
| | Logical Station Number 64 | 2 registers |

| ProLinx Word Address | CCLINK Network RWr Data Memory by Logical Station Number | Network RWr Words Used per Station |
|----------------------|--|------------------------------------|
| 0630 | Logical Station Number 1 | 4 registers |
| 0633 | | |
| 0634 | Logical Station Number 2 | 4 registers |
| 0637 | | |
| 0638 | Logical Station Number 3 | 4 registers |
| 0641 | | |
| 0642 | Logical Station Number 4 | 4 registers |
| 0645 | | |
| 0646 | Logical Station Number 5 to Logical Station Number 63 | 4 registers per Logical Station |
| 0881 | | |
| 0882 | | |
| 0885 | Logical Station Number 64 | 4 registers |
| ProLinx Word Address | CCLINK Network RY Data Memory by Logical Station Number | Network RY Words Used per Station |
| 0900 | Logical Station Number 1 | 2 registers |
| 0901 | | |
| 0902 | Logical Station Number 2 | 2 registers |
| 0903 | | |
| 0904 | Logical Station Number 3 | 2 registers |
| 0905 | | |
| 0906 | Logical Station Number 4 | 2 registers |
| 0907 | | |
| 0908 | Logical Station Number 5 to Logical Station Number 63 | 2 registers per Logical Station |
| 1025 | | |
| 1026 | | |
| 1027 | Logical Station Number 64 | 2 registers |

| ProLinx Word Address | CCLINK Network RWw Data Memory by Logical Station Number | Network RWw Words Used per Station |
|----------------------|--|------------------------------------|
| 1030 1033 | Logical Station Number 1 | 4 registers |
| 1034 1037 | Logical Station Number 2 | 4 registers |
| 1038 1041 | Logical Station Number 3 | 4 registers |
| 1042 1045 | Logical Station Number 4 | 4 registers |
| 1046 1281 | Logical Station Number 5 to Logical Station Number 63 | 4 registers per Logical Station |
| 1282 1285 | Logical Station Number 64 | 4 registers |

5.4 CC-Link Cyclic Data Concepts

Cyclic data refers to the fixed amount of data that will be transferred between the CC-Link network Master Station and each logical Slave Station. Cyclic data transfers are controlled by the CC-Link Master. Since the amount of data that can be transferred is fixed and since the CC-Link Master controls cyclic transfers, there is very little configuration required for the ProLinx gateway for it to be able to pass cyclic data on the CC-Link network. However, some general information about the CC-Link protocol will help you better understand how the ProLinx gateway works.

Most CC-Link devices, including the ProLinx gateway, use separate memory partitions to hold the different types of cyclic data transferred by the protocol. In programmable logic controllers (PLCs) like the Mitsubishi MEL-SEC Q series, for example, memory is usually partitioned according to whether the data is to be input data (received data) or output data (sent data) and according to the type of data to be stored. Single-bit binary data is usually separated from 16-bit integer register data. The cyclic data type partitions for CC-Link are as follows:

- **RX Remote Input Data (for binary inputs)** – The RX memory area holds single-bit binary cyclic data that is received from Stations on the CC-Link network.
- **RY Remote Output Data (for binary outputs)** – The RY memory area holds single-bit binary cyclic data that is sent to Stations on the CC-Link network.
- **RWr Remote Register Data (for register inputs)** – The RWr memory area holds 16-bit integer register cyclic data that is received from Stations on the CC-Link network. Register data areas can hold bit patterns for many different data types, like bit-packed or bit-mapped binary data, byte-packed single-byte integer data, single or double word integer data, ASCII character code data, single- or double-precision floating point data, and more. Integer data can be Unsigned or Signed. This is because the ProLinx gateway does not do any data type interpretation. It just accurately stores and transmits bit patterns without any manipulation of them and without any regard for what kind of data they ultimately represent.
- **RWw Remote Register Data (for register outputs)** – The RWw memory area holds 16-bit integer register cyclic data that is sent to the Stations on the CC-Link network. The RWw registers can hold the same variety of data as the RWr registers.
- **SB Link Special Relay Data (for binary Station Status data)** – The SB memory area holds binary status bit information about the current link status of CC-Link network. For details, refer to the "Status Data" section of the chapter on *Troubleshooting*.
- **SW Special Register Data (for register Station Status data)** – The SW memory area hold register status information about the current link status of CC-Link network. For details, refer to the "Status Data" section of the chapter on *Troubleshooting*.

The following cyclic data types apply to and exist in only Master Stations and Local Stations:

- **Network RX Data** – This data area contains a copy of the entire Master Station RX Data Area, that is, all the cyclic binary data received by the Master Station from all the Slave Stations on the network.
- **Network RY Data** – This data area contains a copy of the entire Master Station RY Data Area, that is, all the cyclic binary data sent from the Master Station to all the Slave Stations on the network.
- **Network RWr Data** – This data area contains a copy of the entire Master Station RWr Data Area, that is, all the cyclic register data received by the Master Station from all the Slave Stations on the network.
- **Network RWw Data** – This data area contains a copy of the entire Master Station RWw Data Area, that is, all the cyclic register data sent from the Master Station to all the Slave Stations on the network.

One important concept to keep in mind is that the designations "input data" and "output data" are always specified from the point of view of the station on which the data resides. That is, on any given station, "input data" will always be data that station received from another station and "output data" will always be data destined to be sent to another station. For example, a Slave station's RY binary output data area will be used to hold data that will be sent from the Slave to the network Master's RX binary input data area. Likewise, the Master's RY binary output data area will be used to hold data to be sent to one or more Slave RX binary input data area or areas.

Another important concept to keep in mind is that the output data from one station will always be transferred to the input area of another station. This is true for Masters as well as Slaves. All Slave input data will come from the network Master's output data areas. All data received by the network Master into its input data areas will come from the various Slaves' output data areas.

The following tables show two typical examples of how data might flow through the ProLinX memory database between two different processors. Both examples show addressing for a Mitsubishi MEL-SEC Q processor as the CC-Link Master system. One example shows addressing for a Rockwell Automation ControlLogix[®] Programmable Automation Controller and the other example shows addressing for a Modicon[®] Quantum PLC system. The addresses shown for those controllers have been arbitrarily assigned for these examples. In actual applications, they are user-selectable and can be changed to suit your specific application.

You should notice:

- Data from the bit write area of the ProLinX goes to the bit read area of the Mitsubishi
- Data from the bit write area of the Mitsubishi goes to the bit read area of the ProLinX
- Data from the register write area of the ProLinX goes to the register read area of the Mitsubishi
- Data from the register write area of the Mitsubishi goes to the register read area of the ProLinX

| ControlLogix CPU Controller Tag Memory Areas | ProLinX Memory addresses | ProLinX CCLINK Data Type Memory Areas | Data Direction | Mitsubishi PLC CC-Link Data Type Memory Areas | Mitsubishi PLC Memory Partition Addresses |
|--|--------------------------|--|----------------|---|---|
| BinaryIn[0] (BOOL Tag Array) | 0000 | CCLINK RX bit area 32 bits per station | ← | CC-Link RY bit area 32 bits per station | Y100 (Y Bit Memory) |
| BinaryIn[159] | 0007 | | | | Y159 |
| InRegisters[0] (INT Tag Array) | 0010 | CCLINK RWw word area 4 words per station | ← | CC-Link RWw word area 4 words per station | D1000 (D Register Memory) |
| InRegisters[15] | 0025 | | | | D1015 |
| BinaryOut[0] (BOOL Tag Array) | 0030 | CCLINK RY bit area 32 bits per station | → | CC-Link RX bit area 32 bits per station | X100 (X Bit Memory) |
| BinaryOut[159] | 0037 | | | | X159 |
| OutRegisters[0] (INT Tag Array) | 0040 | CCLINK RWw word area 4 words per station | → | CC-Link RWw word area 4 words per station | D100 (D Register Memory) |
| OutRegisters[15] | 0055 | | | | D115 |

| Modicon Quantum PLC Modbus Memory Areas | ProLinx Memory addresses | ProLinx CCLINK Data Type Memory Areas | Data Direction | Mitsubishi PLC CC-Link Data Type Memory Areas | Mitsubishi PLC Memory Partition Addresses |
|---|--------------------------------|---|-------------------|--|---|
| 0x0001 (Coils - read/write binary data) 0x0159 | 0000 0007 | CCLINK RX bit area 32 bits per station | ← | CC-Link RY bit area 32 bits per station | Y100 (Y Bit Memory) Y159 |
| 4x0001 (Holding Registers - read/write 16-bit register data) 4x0015 | 0010 0025 | CCLINK RWr word area 4 words per station | ← | CC-Link RWr word area 4 words per station | D1000 (D Register Memory) D1015 |
| 1x0001 (Input Status - read-only binary data) 1x0159 | 0030 0037 | CCLINK RY bit area 32 bits per station | → | CC-Link RX bit area 32 bits per station | X100 (X Bit Memory) X159 |
| 3x0001 (Input Registers - read-only 16-bit register data) 3x0015 | 0040 0055 | CCLINK RWr word area 4 words per station | → | CC-Link RWr word area 4 words per station | D100 (D Register Memory) D115 |

5.5 CC-Link Transient Data Messaging Concepts

WARNING: Unlike Cyclic Data transfers, which happen almost automatically from the ProLinX gateway's perspective, Transient Messaging requires much more involvement by the user to configure, manage, and maintain data transfers. Before attempting Transient Messaging, the user must thoroughly understand the details of this feature of the CC-Link protocol and must be proficient in using that knowledge. Improper use of Transient Messaging could result in unexpected system behavior, resulting in potential damage to equipment and/or injury to personnel.

5.5.1 General

The Transient Messaging capability of the CC-Link protocol allows for greater flexibility in the way users may transfer data on the network than what is possible using Cyclic Data transfers. Smaller or larger amounts of data can be transferred with Transient Messaging than is possible within the more rigid Cyclic Data structure; and data transfers with Transient Messaging are conditional, not periodic.

Unlike Cyclic Data transfers, which are controlled by the CC-Link Master alone and which happen at a timed, periodic, polling rate, Transient Messages are controlled by the originating station, which could be a Master Station, a Local Station, or an Intelligent Device Station. Transient Messages are non-periodic, that is, they are not scheduled to happen at a regular interval, like Cyclic Data transfers do. Transient Messages are sent only when "triggered" by a logical event. In the ProLinX gateway, the logical event that will trigger a Transient Message is when a non-zero value is stored into a gateway database register designated as the *Trigger Register* in the Transient Message configuration.

When a *Trigger Register* is set to a non-zero value, the ProLinX firmware will create and transmit a Transient Message that is based on the Command configuration contained in the configuration file that was downloaded to the gateway. Once the Transient Message has been sent, the firmware will set the *Trigger Register* value back to zero to indicate the trigger was received and acted upon.

Trigger Registers can be any valid user memory database address, from 0 to 9999 (10,000 register database). This address range includes the CC-Link Cyclic Data area, the Special Status Data areas (SB and SW), the Network Data area, and the Transient Data area. This means that any address in the gateway's database may be monitored for the appearance of a non-zero value as a way to trigger execution of a Transient Message. Therefore, care must be taken when choosing a *Trigger Register* to be sure it will contain non-zero values only when its associated Transient Message needs to be triggered to prevent inadvertent message transmission and avoid overloading the network with Transient Messages.

5.5.2 CCLINK Transient Data Message Memory Areas

To fully understand all the Transient Message options, you must first understand the different memory areas that may be accessed using Transient Messages. There are four primary memory areas to consider:

- 1 ProLinX Gateway Memory Database Area - This area is the total 10,000 word (10,000 16-bit registers) of physical memory that is available on the gateway. All of this memory area is generally available to whatever other communications protocol driver is installed on the ProLinX gateway along with the CCLINK protocol driver, such as the DFNT EtherNet/IP driver or the MNET Modbus TCP/IP driver. This entire memory database area can also be used as the source or destination address for the *Internal Address* parameter of Transient Message commands.

This area includes the memory addresses assigned for use by the CCLINK driver and directly accessible by the CC-Link network Master; so, care must be taken with setting the *Internal Address* parameter of Transient Message commands so that you do not overwrite CCLINK data areas with Transient Message Data unless you intend to do so.

To avoid inadvertent corruption of the CCLINK Cyclic Data Areas, any *Internal Addresses* used in Transient Message commands should be confined to those assigned specifically for Transient Message Data. These addresses start at gateway memory address 1300 and continue up to address 9999.

- 2 ProLinX Gateway CCLINK Driver-accessible Memory Area - This area is a sub-set of the entire 10,000 word gateway database and is outlined and explained in the "ProLinX CCLINK User Data Memory" section of the *Reference* chapter. It includes all the Cyclic Data Areas and the Transient Message Data Area.

To avoid inadvertent corruption of the CCLINK Cyclic Data Areas, any *Internal Addresses* used in Transient Message commands should be confined to those assigned specifically for Transient Message Data. These addresses start at gateway memory address 1300 and continue up to address 9999.

- 3 CC-Link Communications Network Data Buffer Area - This area exists as a memory buffer on the CC-Link communications port hardware. Every CC-Link device on the network will have this memory buffer area built into its hardware. This memory buffer on each device will receive cyclic updates from the CC-Link Master on the network and the data in this memory buffer is what will be copied to the ProLinX Gateway CCLINK Driver-accessible Memory Area. So, for all practical purposes, the two memory areas will contain the same data. The only reason to make a distinction between the two is because different types of Transient Messages will access these two memory areas separately.

Command Attribute 4 will access this buffer data directly from the CC-Link hardware on whatever *Node Address* (Station Address) is set in the Command; but, since this data all comes from the Master Station, all stations should contain the same data, the best practice would be to always use the Master Station *Node Address* for Command Attribute 4 messages.

- 4 CC-Link Data Memory Database Areas of devices on the network other than the ProLinX Gateway - These areas exist on all Slave Stations and are analogous to the ProLinX CCLINK Driver-accessible Memory Area of the gateway. These areas are the ones that will be accessed by using Command Attribute 5.

5.6 Specifications

5.6.1 Functional Specifications - CC-Link

CC-Link technology is based on an Application Specific Integrated Circuit (ASIC) designed and provided by Mitsubishi Electric Automation. Each CC-Link logical station transfers 4 words as 16-bit register data and 32 bits as binary I/O data to the Master station and receives an additional 4 words and 32 bits from the Master Station. The CCLINK gateway can occupy up to 4 consecutive stations on the CC-Link network increasing its I/O data transfer capacity.

| | |
|--|--|
| Maximum number of station addresses occupied | 4 stations, consecutive addresses |
| Maximum Number of Devices per network | 26-64 Devices depending on type of devices or stations configured |
| Device Types Supported | Intelligent Device and Local Station |
| CC-Link Version supported | CC-Link Version 1.10 cyclic data transmission |
| Message handling | Cyclic Messages and Transient Messages |
| Cyclic Data Capacity | 4 Slave station supporting 4 words and 32bits per station for a total of 24 input data words and 24 output data words per gateway. |
| Additional I/O Data Transfer Capacity | Transient Messaging extends the data transfer capacity to more than 8,000 additional words |
| Transient Message Commands | System Information, Memory Access Information, RUN, STOP, Line Test. Memory Read and Memory Write commands |
| Communication speed | 10 Mbps, 5 Mbps, 2.5 Mbps, 625 kbps, 156 kbps |
| Transmission path format | Bus format (EIA RS485 conformance) |
| Transmission format | HDLC conformance |
| Error control system | CRC (X16+X12+X5+1) |

5.7 Conformance Testing

Conformance testing through the CC-Link partner Association (CLPA) is in progress and ensures that the gateway meets the performance specifications required to become CC-Link certified.


5.7.1 General Specifications

ProLinx[®] Communication Gateways provide connectivity for two or more dissimilar network types. The gateways, encased in sturdy extruded aluminum, are stand-alone, DIN-rail-mounted solutions that provide data transfer between many of today's most widely used industrial automation protocols.

5.7.2 Using ProSoft Configuration Builder


ProSoft Configuration Builder (PCB) provides a convenient way to manage gateway configuration files customized to meet your application needs. *PCB* is not only a powerful solution for new configuration files, but also allows you to import information from previously installed (known working) configurations to new projects.

5.7.3 Hardware Specifications



| Specification | Description | | | | | | | | | | | | |
|---------------------------|--|-----|-------------|----|---------------------------|----|---------------------------|----|----------------|-----|--------|----|--------------|
| Power Supply | 24 VDC nominal 18 to 32 VDC allowed Positive, Negative, and Ground terminals 2.5 mm screwdriver blade-sized terminals | | | | | | | | | | | | |
| Current Load | 500 mA max@ 32 VDC max | | | | | | | | | | | | |
| Operating Temperature | -20 to 50°C (-4 to 122°F) | | | | | | | | | | | | |
| Storage Temperature | -40 to 85°C (-40 to 185°F) | | | | | | | | | | | | |
| Relative Humidity | 5% to 95% (non-condensing) | | | | | | | | | | | | |
| Dimensions | Standard: 5.20H x 2.07W x 4.52D inches (13.2cmH x 5.25cmW x 11.48cmD) Extended: 5.20H x 2.73W x 4.52D inches (13.2cmH x 6.934cmW x 11.48cmD) | | | | | | | | | | | | |
| General LED Indicators | Power and General Status Application Status Serial Port Activity LED Serial Activity and Error LED Status | | | | | | | | | | | | |
| CC-Link LED Indicators | Run (Network Status) L Run (Data Link Execution) L Err (Data Link Comm Error) SD (Sending Data LED) RD (Receiving Data LED) ERR (Switch Setting Error) | | | | | | | | | | | | |
| Configuration Serial Port | DB-9M RS-232 only No hardware handshaking | | | | | | | | | | | | |
| Ethernet Port | RJ45 Connector, 10Mbit, half-duplex only Link and Activity LED indicators Electrical Isolation 1500 V rms at 50 Hz to 60 Hz for 60 s, applied as specified in section 5.3.2 of IEC 60950: 1991 Ethernet Broadcast Storm Resiliency = less than or equal to 5000 [ARP] frames-per-second and less than or equal to 5 minutes duration | | | | | | | | | | | | |
| CC-Link Interface |  <table border="1"> <thead> <tr> <th>Pin</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>DA</td> <td>Data Communication line A</td> </tr> <tr> <td>DB</td> <td>Data Communication line B</td> </tr> <tr> <td>DG</td> <td>Digital Ground</td> </tr> <tr> <td>SLD</td> <td>Shield</td> </tr> <tr> <td>FG</td> <td>Frame Ground</td> </tr> </tbody> </table> | Pin | Description | DA | Data Communication line A | DB | Data Communication line B | DG | Digital Ground | SLD | Shield | FG | Frame Ground |
| Pin | Description | | | | | | | | | | | | |
| DA | Data Communication line A | | | | | | | | | | | | |
| DB | Data Communication line B | | | | | | | | | | | | |
| DG | Digital Ground | | | | | | | | | | | | |
| SLD | Shield | | | | | | | | | | | | |
| FG | Frame Ground | | | | | | | | | | | | |
| Shipped with Each Unit | Mini-DIN to DB-9M serial cable 4 ft RS-232 configuration cable 2.5mm screwdriver CD (docs and Configuration utility) CC-Link to Terminal Block connector | | | | | | | | | | | | |

5.8 RS-232 Configuration/Debug Port

This port is physically an eight-pin, Mini-DIN8F connection. A Mini-DIN8M to DB9M adapter cable is included with the gateway. This port permits a PC-based terminal emulation program to view configuration and status data in the gateway and to control the gateway. Here are the cable pinouts for RS-232 communication on this port.



5.9 DB9 to Mini-DIN Adaptor (Cable 09)



5.10 CC-Link Port



| Pin | Description |
|-----|---------------------------|
| DA | Data Communication line A |
| DB | Data Communication line B |
| DG | Digital Ground |
| SLD | Shield |
| FG | Frame Ground |

6 Support, Service & Warranty

In This Chapter

| | |
|---|-----|
| ❖ Contacting Technical Support | 97 |
| ❖ Return Material Authorization (RMA) Policies and Conditions | 99 |
| ❖ LIMITED WARRANTY..... | 100 |

Contacting Technical Support

ProSoft Technology, Inc. (ProSoft) is committed to providing the most efficient and effective support possible. Before calling, please gather the following information to assist in expediting this process:

- 1 Product Version Number
- 2 System architecture
- 3 Network details

If the issue is hardware related, we will also need information regarding:

- 1 Module configuration and associated ladder files, if any
- 2 Module operation and any unusual behavior
- 3 Configuration/Debug status information
- 4 LED patterns
- 5 Details about the serial, Ethernet or fieldbus devices interfaced to the module, if any.

Note: For technical support calls within the United States, an after-hours answering system allows 24-hour/7-days-a-week pager access to one of our qualified Technical and/or Application Support Engineers. Detailed contact information for all our worldwide locations is available on the following page.

| | |
|--|--|
| Internet | Web Site: www.prosoft-technology.com/support E-mail address: support@prosoft-technology.com |
| Asia Pacific (location in Malaysia) | Tel: +603.7724.2080, E-mail: asiapc@prosoft-technology.com Languages spoken include: Chinese, English |
| Asia Pacific (location in China) | Tel: +86.21.5187.7337 x888, E-mail: asiapc@prosoft-technology.com Languages spoken include: Chinese, English |
| Europe (location in Toulouse, France) | Tel: +33 (0) 5.34.36.87.20, E-mail: support.EMEA@prosoft-technology.com Languages spoken include: French, English |
| Europe (location in Dubai, UAE) | Tel: +971-4-214-6911, E-mail: mea@prosoft-technology.com Languages spoken include: English, Hindi |
| North America (location in California) | Tel: +1.661.716.5100, E-mail: support@prosoft-technology.com Languages spoken include: English, Spanish |
| Latin America (Oficina Regional) | Tel: +1-281-2989109, E-Mail: latinam@prosoft-technology.com Languages spoken include: Spanish, English |
| Latin America (location in Puebla, Mexico) | Tel: +52-222-3-99-6565, E-mail: soporte@prosoft-technology.com Languages spoken include: Spanish |
| Brasil (location in Sao Paulo) | Tel: +55-11-5083-3776, E-mail: brasil@prosoft-technology.com Languages spoken include: Portuguese, English |

6.1 Return Material Authorization (RMA) Policies and Conditions

The following Return Material Authorization (RMA) Policies and Conditions (collectively, "RMA Policies") apply to any returned product. These RMA Policies are subject to change by ProSoft Technology, Inc., without notice. For warranty information, see Limited Warranty (page 100). In the event of any inconsistency between the RMA Policies and the Warranty, the Warranty shall govern.

6.1.1 Returning Any Product

- a) In order to return a Product for repair, exchange, or otherwise, the Customer must obtain a Return Material Authorization (RMA) number from ProSoft Technology and comply with ProSoft Technology shipping instructions.
- b) In the event that the Customer experiences a problem with the Product for any reason, Customer should contact ProSoft Technical Support at one of the telephone numbers listed above (page 97). A Technical Support Engineer will request that you perform several tests in an attempt to isolate the problem. If after completing these tests, the Product is found to be the source of the problem, we will issue an RMA.
- c) All returned Products must be shipped freight prepaid, in the original shipping container or equivalent, to the location specified by ProSoft Technology, and be accompanied by proof of purchase and receipt date. The RMA number is to be prominently marked on the outside of the shipping box. Customer agrees to insure the Product or assume the risk of loss or damage in transit. Products shipped to ProSoft Technology using a shipment method other than that specified by ProSoft Technology, or shipped without an RMA number will be returned to the Customer, freight collect. Contact ProSoft Technical Support for further information.
- d) A 10% restocking fee applies to all warranty credit returns, whereby a Customer has an application change, ordered too many, does not need, etc. Returns for credit require that all accessory parts included in the original box (i.e.; antennas, cables) be returned. Failure to return these items will result in a deduction from the total credit due for each missing item.

6.1.2 Returning Units Under Warranty

A Technical Support Engineer must approve the return of Product under ProSoft Technology's Warranty:

- a) A replacement module will be shipped and invoiced. A purchase order will be required.
- b) Credit for a product under warranty will be issued upon receipt of authorized product by ProSoft Technology at designated location referenced on the Return Material Authorization
 - i. If a defect is found and is determined to be customer generated, or if the defect is otherwise not covered by ProSoft Technology's warranty, there will be no credit given. Customer will be contacted and can request module be returned at their expense;
 - ii. If defect is customer generated and is repairable, customer can authorize ProSoft Technology to repair the unit by providing a purchase order for 30% of the current list price plus freight charges, duties and taxes as applicable.

6.1.3 Returning Units Out of Warranty

- a) Customer sends unit in for evaluation to location specified by ProSoft Technology, freight prepaid.
- b) If no defect is found, Customer will be charged the equivalent of \$100 USD, plus freight charges, duties and taxes as applicable. A new purchase order will be required.
- c) If unit is repaired, charge to Customer will be 30% of current list price (USD) plus freight charges, duties and taxes as applicable. A new purchase order will be required or authorization to use the purchase order submitted for evaluation fee.

The following is a list of non-repairable units:

ScanPort Adapters

- 1500 - All
- 1550 - Can be repaired only if defect is the power supply
- 1560 - Can be repaired only if defect is the power supply

inRAx Modules

- 3150 - All
- 3170 - All
- 3250
- 3300
- 3350
- 3600 - All
- 3700
- 3750
- 3800-MNET

ProLinx Standalone Gateways

- 4xxx - All (No hardware available to do repairs)

6.2 LIMITED WARRANTY

This Limited Warranty ("Warranty") governs all sales of hardware, software, and other products (collectively, "Product") manufactured and/or offered for sale by ProSoft Technology, Incorporated (ProSoft), and all related services provided by ProSoft, including maintenance, repair, warranty exchange, and service programs (collectively, "Services"). By purchasing or using the Product or Services, the individual or entity purchasing or using the Product or Services ("Customer") agrees to all of the terms and provisions (collectively, the "Terms") of this Limited Warranty. All sales of software or other intellectual property are, in addition, subject to any license agreement accompanying such software or other intellectual property.

6.2.1 What Is Covered By This Warranty

- a) *Warranty On New Products:* ProSoft warrants, to the original purchaser, that the Product that is the subject of the sale will (1) conform to and perform in accordance with published specifications prepared, approved and issued by ProSoft, and (2) will be free from defects in material or workmanship; provided these warranties only cover Product that is sold as new. This Warranty expires three (3) years from the date of shipment for Product purchased **on or after** January 1st, 2008, or one (1) year from the date of shipment for Product purchased **before** January 1st, 2008 (the "Warranty Period"). If the Customer discovers within the Warranty Period a failure of the Product to conform to specifications, or a defect in material or workmanship of the Product, the Customer must promptly notify ProSoft by fax, email or telephone. In no event may that notification be received by ProSoft later than 39 months from date of original shipment. Within a reasonable time after notification, ProSoft will correct any failure of the Product to conform to specifications or any defect in material or workmanship of the Product, with either new or remanufactured replacement parts. ProSoft reserves the right, and at its sole discretion, may replace unrepairable units with new or remanufactured equipment. All replacement units will be covered under warranty for the 3 year period commencing from the date of original equipment purchase, not the date of shipment of the replacement unit. Such repair, including both parts and labor, will be performed at ProSoft's expense. All warranty service will be performed at service centers designated by ProSoft.
- b) *Warranty On Services:* Materials and labor performed by ProSoft to repair a verified malfunction or defect are warranted in the terms specified above for new Product, provided said warranty will be for the period remaining on the original new equipment warranty or, if the original warranty is no longer in effect, for a period of 90 days from the date of repair.

6.2.2 What Is Not Covered By This Warranty

- a) ProSoft makes no representation or warranty, expressed or implied, that the operation of software purchased from ProSoft will be uninterrupted or error free or that the functions contained in the software will meet or satisfy the purchaser's intended use or requirements; the Customer assumes complete responsibility for decisions made or actions taken based on information obtained using ProSoft software.
- b) This Warranty does not cover the failure of the Product to perform specified functions, or any other non-conformance, defects, losses or damages caused by or attributable to any of the following: (i) shipping; (ii) improper installation or other failure of Customer to adhere to ProSoft's specifications or instructions; (iii) unauthorized repair or maintenance; (iv) attachments, equipment, options, parts, software, or user-created programming (including, but not limited to, programs developed with any IEC 61131-3, "C" or any variant of "C" programming languages) not furnished by ProSoft; (v) use of the Product for purposes other than those for which it was designed; (vi) any other abuse, misapplication, neglect or misuse by the Customer; (vii) accident, improper testing or causes external to the Product such as, but not limited to, exposure to extremes of temperature or humidity, power failure or power surges; or (viii) disasters such as fire, flood, earthquake, wind and lightning.

- c) The information in this Agreement is subject to change without notice. ProSoft shall not be liable for technical or editorial errors or omissions made herein; nor for incidental or consequential damages resulting from the furnishing, performance or use of this material. The user guide included with your original product purchase from ProSoft contains information protected by copyright. No part of the guide may be duplicated or reproduced in any form without prior written consent from ProSoft.

6.2.3 Disclaimer Regarding High Risk Activities

Product manufactured or supplied by ProSoft is not fault tolerant and is not designed, manufactured or intended for use in hazardous environments requiring fail-safe performance including and without limitation: the operation of nuclear facilities, aircraft navigation of communication systems, air traffic control, direct life support machines or weapons systems in which the failure of the product could lead directly or indirectly to death, personal injury or severe physical or environmental damage (collectively, "high risk activities"). ProSoft specifically disclaims any express or implied warranty of fitness for high risk activities.

6.2.4 Intellectual Property Indemnity

Buyer shall indemnify and hold harmless ProSoft and its employees from and against all liabilities, losses, claims, costs and expenses (including attorney's fees and expenses) related to any claim, investigation, litigation or proceeding (whether or not ProSoft is a party) which arises or is alleged to arise from Buyer's acts or omissions under these Terms or in any way with respect to the Products. Without limiting the foregoing, Buyer (at its own expense) shall indemnify and hold harmless ProSoft and defend or settle any action brought against such Companies to the extent based on a claim that any Product made to Buyer specifications infringed intellectual property rights of another party. ProSoft makes no warranty that the product is or will be delivered free of any person's claiming of patent, trademark, or similar infringement. The Buyer assumes all risks (including the risk of suit) that the product or any use of the product will infringe existing or subsequently issued patents, trademarks, or copyrights.

- a) Any documentation included with Product purchased from ProSoft is protected by copyright and may not be duplicated or reproduced in any form without prior written consent from ProSoft.
- b) ProSoft's technical specifications and documentation that are included with the Product are subject to editing and modification without notice.
- c) Transfer of title shall not operate to convey to Customer any right to make, or have made, any Product supplied by ProSoft.
- d) Customer is granted no right or license to use any software or other intellectual property in any manner or for any purpose not expressly permitted by any license agreement accompanying such software or other intellectual property.
- e) Customer agrees that it shall not, and shall not authorize others to, copy software provided by ProSoft (except as expressly permitted in any license agreement accompanying such software); transfer software to a third party separately from the Product; modify, alter, translate, decode, decompile, disassemble, reverse-engineer or otherwise attempt to derive the source code of the software or create derivative works based on the software; export the software or underlying technology in contravention of applicable US and international export laws and regulations; or use the software other than as authorized in connection with use of Product.
- f) **Additional Restrictions Relating To Software And Other Intellectual Property**

In addition to compliance with the Terms of this Warranty, Customers purchasing software or other intellectual property shall comply with any license agreement accompanying such software or other intellectual property. Failure to do so may void this Warranty with respect to such software and/or other intellectual property.

6.2.5 Disclaimer of all Other Warranties

The Warranty set forth in What Is Covered By This Warranty (page 101) are in lieu of all other warranties, express or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose.

6.2.6 Limitation of Remedies **

In no event will ProSoft or its Dealer be liable for any special, incidental or consequential damages based on breach of warranty, breach of contract, negligence, strict tort or any other legal theory. Damages that ProSoft or its Dealer will not be responsible for include, but are not limited to: Loss of profits; loss of savings or revenue; loss of use of the product or any associated equipment; loss of data; cost of capital; cost of any substitute equipment, facilities, or services; downtime; the claims of third parties including, customers of the Purchaser; and, injury to property.

** Some areas do not allow time limitations on an implied warranty, or allow the exclusion or limitation of incidental or consequential damages. In such areas, the above limitations may not apply. This Warranty gives you specific legal rights, and you may also have other rights which vary from place to place.

6.2.7 Time Limit for Bringing Suit

Any action for breach of warranty must be commenced within 39 months following shipment of the Product.

6.2.8 No Other Warranties

Unless modified in writing and signed by both parties, this Warranty is understood to be the complete and exclusive agreement between the parties, suspending all oral or written prior agreements and all other communications between the parties relating to the subject matter of this Warranty, including statements made by salesperson. No employee of ProSoft or any other party is authorized to make any warranty in addition to those made in this Warranty. The Customer is warned, therefore, to check this Warranty carefully to see that it correctly reflects those terms that are important to the Customer.

6.2.9 Allocation of Risks

This Warranty allocates the risk of product failure between ProSoft and the Customer. This allocation is recognized by both parties and is reflected in the price of the goods. The Customer acknowledges that it has read this Warranty, understands it, and is bound by its Terms.

6.2.10 Controlling Law and Severability

This Warranty shall be governed by and construed in accordance with the laws of the United States and the domestic laws of the State of California, without reference to its conflicts of law provisions. If for any reason a court of competent jurisdiction finds any provisions of this Warranty, or a portion thereof, to be unenforceable, that provision shall be enforced to the maximum extent permissible and the remainder of this Warranty shall remain in full force and effect. Any cause of action with respect to the Product or Services must be instituted in a court of competent jurisdiction in the State of California.

Index

[

[CCLink Command Attribute x] • 16, 19
[CCLK Config] • 16
[Data Map] • 42

A

Access Code • 22
Access Codes for Attribute 4 • 22, 26
Access Codes for Attribute 5 • 23, 33
Adding a Module • 14
Agency Approvals and Certifications • 4
Alive Check • 18
Allocation of Risks • 103
Attribute Code • 22

B

Base Module LEDs • 51

C

CC-Link • 7
CC-Link Access to Gateway Database • 9
CC-Link Cyclic Data Concepts • 85
CC-Link Interface-Specific LEDs • 51
CC-Link Overview • 77
CC-Link Port • 95
CC-Link Protocol Configuration • 16
CCLINK Transient Data Message Memory Areas • 89
CC-Link Transient Data Messaging Concepts • 16, 19, 88
Command Attribute 5 • 33
Command Attribute Code 4 • 26
Comment • 25
Conditional Read Example • 27
Conditional Write Example to Other Than a Master Station • 38
Configuring Module Parameters • 15
Configuring the Gateway • 13
Configuring Transient Messages • 19
Contacting Technical Support • 97, 99
Controlling Law and Severability • 104
Creating Optional Comment Entries • 15

D

DB9 to Mini-DIN Adaptor (Cable 09) • 94
Delay Preset • 44
Diagnostics and Troubleshooting • 47
Disclaimer of all Other Warranties • 103
Disclaimer Regarding High Risk Activities • 102
Downloading a File from PC to the Module • 46

E

Enable • 17, 20
Entering the Command Offset Address • 31
Error Data • 65
Example Commands • 26

F

From Address • 42
Functional Specifications - CC-Link • 90

G

General • 88
General Overview • 76
General Specifications • 91

H

Hardware Specifications • 92
How to Contact Us • 2

I

Important Installation Instructions • 3
Installing ProSoft Configuration Builder Software • 11
Intellectual Property Indemnity • 102
Internal Address • 20
Internal Database • 8

K

Keystrokes • 50

L

LED Indicators • 51
Limitation of Remedies ** • 103
LIMITED WARRANTY • 99, 100

N

Navigation • 50
No Other Warranties • 103
Node Address • 21

O

Offset Address • 25

P

Pinouts • 3, 94
PLX Markings • 3
Printing a Configuration File • 45
ProLinX CCLINK Memory Area Breakdown by Logical Station • 81
ProLinX CCLINK Memory Map Overview • 79
ProLinX CCLINK User Data Memory • 79
ProLinX Gateways with Ethernet Ports • 3
ProLinX Local Station Network Data Area Breakdown • 82
ProLinX® Products Warnings • 3
ProSoft Technology® Product Documentation • 2

R

- Reference • 76
- Register Count • 21, 42
- Remote Inputs Example • 29
- Required Hardware • 47
- Return Material Authorization (RMA) Policies and Conditions • 99
- Returning Any Product • 99
- Returning Units Out of Warranty • 100
- Returning Units Under Warranty • 99
- RS-232 Configuration/Debug Port • 93

S

- Slave Type • 17
- Specifications • 90
- Station Number • 17
- Stations Occupied • 17, 18
- Status Data • 52
- Support, Service & Warranty • 97
- Swap Code • 21, 43

T

- Time Limit for Bringing Suit • 103
- Times Setting • 18
- To Address • 42
- Transient Message Bit-level Access • 24, 25, 26, 31
- Transmission Speed • 17
- Trigger Register • 20
- Types of CC-Link Data Transfers • 77
- Types of CC-Link Slave Stations • 78

U

- Using ProSoft Configuration Builder • 91
- Using ProSoft Configuration Builder (PCB) for Diagnostics • 47
- Using the CommonNet Data Map • 41
- Using the Diagnostic Window in ProSoft Configuration Builder • 48
- Using the Online Help • 13

W

- What Is Covered By This Warranty • 101, 103
- What Is Not Covered By This Warranty • 101
- Writing to Counters, Timers or Retentive Timers • 35
- Writing to the File Register Data Type • 37
- Writing to the Remote Input RX Data Area • 33

Y

- Your Feedback Please • 2