

Where Automation Connects.



ILX56-PND PROFINET Device ControlLogix®

October 13, 2025

Your Feedback Please

We always want you to feel that you made the right decision to use our products. If you have suggestions, comments, compliments or complaints about our products, documentation, or support, please write or call us.

ProSoft Technology, Inc.

+1 (661) 716-5100

+1 (661) 716-5101 (Fax)

www.prosoft-technology.com ps.support@belden.com

ILX56-PND User Manual For Public Use.

October 13, 2025

ProSoft Technology®, is a registered copyright of ProSoft Technology, Inc. All other brand or product names are or may be trademarks of, and are used to identify products and services of, their respective owners.

Content Disclaimer

This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither ProSoft Technology nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. Information in this document including illustrations, specifications and dimensions may contain technical inaccuracies or typographical errors. ProSoft Technology makes no warranty or representation as to its accuracy and assumes no liability for and reserves the right to correct such inaccuracies or errors at any time without notice. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of ProSoft Technology. All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components. When devices are used for applications with technical safety requirements, the relevant instructions must be followed. Failure to use ProSoft Technology software or approved software with our hardware products may result in injury, harm, or improper operating results. Failure to observe this information can result in injury or equipment damage.

© 2025 ProSoft Technology. All Rights Reserved.



For professional users in the European Union

If you wish to discard electrical and electronic equipment (EEE), please contact your dealer or supplier for further information.



Prop 65 Warning – Cancer and Reproductive Harm – <u>www.P65Warnings.ca.gov</u>

Agency Approvals and Certifications

Please visit our website: www.prosoft-technology.com

ProSoft Technology, Inc. Page 2 of 62

Table of Contents

1	Preface		5
	1.1	Introduction to the ILX56-PND	5
	1.2	Features	-
	1.3	Architecture	
	1.4	Additional Information	•
	1.5	Support	
	1.5	Support	О
2	Installatio	on	9
	2.1	Module Layout	9
3	Setup		11
	3.1	Install Configuration Software	11
	3.2	Creating a New Project	
	3.3	ILX56-PND Configuration	
	3.3.1	<u> </u>	
		General	
	3.3.2	PROFINET	
	3.4	Slot Configuration	
	3.4.1	Add Module	
	3.4.2	Delete Module	
	3.5	Mapping	
	3.6	Advanced	
	3.7	Module Download	
	3.8	Studio 5000 Configuration	
	3.8.1	Standard Add-On Profile	
	3.8.2	Generic Profile	31
	3.9	Logix Mapping	33
4	Operation	1	38
_	<u> </u>		
	4.1	Logix Operation	
	4.1.1	PND Module Status	
	4.1.2	PND Control	
	4.1.3	IO Data Status (IOPS / IOCS)	41
5	SD Card		43
	5.1	Firmware	43
	5.2	Configuration	
	5.2.1	Save Configuration File to SD Card	
	5.2.2	Exporting the Configuration File	
c	Cirmurara	unavada	46
<u>6</u>	Firmware	upgraue	46
7	Media Re	dundancy Protocol (MRP)	48
	7.1	Basic Rules	49

8 Diagnost	tics	50
8.1	LEDs	50
8.1	Module Status Monitoring	
8.1.1	General	
8.1.2	Device Status	54
8.1.3	PROFINET Statistics	55
8.1.4	Advanced	
8.2	Module Event Log	57
9 Technica	al Specifications	59
9.1	Electrical	59
9.2	PROFINET	
9.3	ControlLogix	
9.4	Certifications	
10 Appendi	x	60
10.1	PROFINET Response Error Codes	60
11 Support,	Service, and Warranty	62
11.1	Contacting Technical Support	62
11.2	Warranty Information	

1 Preface

1.1 Introduction to the ILX56-PND

This document describes the installation, operation, and diagnostics of the ProSoft ILX56-PND PROFINET Device module. The ILX56-PND operates as a PROFINET Device allowing a PROFINET Controller to configure, parameterize, and exchanging data with the module.

The ILX56-PND slots into a 1756 ControlLogix backplane and operates as a PROFINET Device, allowing the data from a PROFINET Controller to be exchanged with the ControlLogix controller.




Figure 1.1 – Typical ILX56-PND PROFINET architecture

The module is configured using the PLX50 Configuration Utility software from ProSoft.

ProSoft Technology, Inc.

Page 5 of 62

1.2 Features

- The ILX56-PND module operates as a PROFINET Device.
- Exchange up to 1440 bytes of input (and status) data and 1440 bytes of output (and control) data between the ControlLogix controller and the PROFINET Controller.
- Cyclic communication with a PROFINET Controller using PROFINET Real Time (RT) data exchange.
- Data formatted into engineering units for ControlLogix platform by using the automatically generated mapping imports for Logix User Defined Data Types (UDTs).
- The module supports Media Redundancy Protocol (MRP) and can operate as a MRP Client.
- SD Card can be used for firmware and configuration backup.
- The module supports PROFINET Controllers using System Redundancy S2.
- Complies with PROFINET conformance class B.
- Statistics and diagnostics supported for the PROFINET device.
- PI Certified



1.3 Architecture

The figures below provide some typical examples of network configurations.




Figure 1.2 – Basic Configuration

ProSoft Technology, Inc. Page 6 of 62




Figure 1.3 – Basic Configuration with PROFINET MRP




Figure 1.4 – Redundant ControlLogix and S2 Redundant PND Configuration with PROFINET MRP

ProSoft Technology, Inc. Page 7 of 62

1.4 Additional Information

The following documents contain additional information that can assist with installation and operation.

Resource	Link
PLX50 Configuration Utility Installation	www.prosoft-technology.com
ILX56-PND User Manual	www.prosoft-technology.com
ILX56-PND Datasheet	

Table 1.1 - Additional Information

1.5 Support

Technical support is provided via the Web (in the form of User Manuals, FAQ, Datasheets etc.) to assist with installation, operation, and diagnostics.

Additional support:

Resource	Link
Contact us	www.prosoft-technology.com
Support email	ps.support@belden.com

Table 1.2 - Support Details

ProSoft Technology, Inc. Page 8 of 62

2 Installation

2.1 Module Layout

The ILX56-PND module has two PROFINET (Ethernet) ports on the front of the module. These ports support Full- and Half-duplex, at speeds of 10Mbit/s, 100Mbit/s, or 1Gbit/s.

Note: All required power for the module is derived from the ControlLogix backplane.

The module provides 3 diagnostic LEDs and a 4-character alpha-numeric LED display. The LED display provides the mode and status of the module.



Figure 2.1 – ILX56-PND front view

ProSoft Technology, Inc.

Page 9 of 62




Figure 2.2 - ILX56-PND bottom view

Located at the bottom of the module are four DIP Switches and an SD memory card slot. These switches can only be accessed when the module is removed from the ControlLogix chassis.

DIP Switch	Description
DIP Switch 1	Used to force the module into Safe Mode . When in Safe Mode , the module will not load the application firmware and will wait for new firmware to be downloaded. This should only be used in the rare occasion when a firmware update was interrupted at a critical stage.
DIP Switch 2	Used to prevent changes to the configuration.
DIP Switch 3	Reserved
DIP Switch 4	Reserved

Table 2.1 – DIP Switch Settings

This section of the document will walk you through the set-up process needed to use the ILX56-PND module properly.

ProSoft Technology, Inc. Page 10 of 62

3 Setup

This chapter covers the ILX56-PND configuration process.

3.1 Install Configuration Software

The ILX56-PND configuration is done in the ProSoft PLX50 Configuration Utility. This software can be downloaded from www.prosoft-technology.com.




Figure 3.1 – PLX50 Configuration Utility Environment

ProSoft Technology, Inc. Page 11 of 62

3.2 Creating a New Project

Before configuring the ILX56-PND, a new PLX50 Configuration Utility project must be created.

1 Under the *File* menu, select **NEW**. A PLX50 Configuration Utility Design Tool project is created, displaying the *Project Explorer* tree view.




Figure 3.2 - Creating a new project

2 Add a new device by selecting ADD under the Device menu.




Figure 3.3 - Adding a new device

ProSoft Technology, Inc. Page 12 of 62

In the Add New Device window select the ILX56-PND and click the Οκ button.




Figure 3.4 - Select ILX56-PND

4 The ILX56-PND Configuration window opens. The device configuration window can be reopened by either double-clicking the module in the *Project Explorer* tree or right-clicking on the module and selecting **CONFIGURATION**.




Figure 3.5 – ILX56-PND Configuration

ProSoft Technology, Inc. Page 13 of 62

3.3 ILX56-PND Configuration

The ILX56-PND configuration takes place within the PLX50 Configuration Utility environment.

Note: Refer to section *1.4 Additional Information* for documentation and installation links for the ProSoft PLX50 Configuration Utility.

3.3.1 General

The *General* tab of the ILX56-PND Configuration window is opened by either double-clicking on the module in the tree, or right-clicking the module and selecting **CONFIGURATION**.




Figure 3.6 – ILX56-PND General configuration

ProSoft Technology, Inc. Page 14 of 62

The General configuration consists of the following parameters:

Parameter	Description
Identity	·
Module Name	User-defined name to identify the ILX56-PND module.
	Note : This name must match the instance name assigned to the module in the Studio 5000 IO tree.
Description	Provides a detailed description of the application for the module.
Logix	
Profile	The Studio 5000 profile used to instantiate the ILX56-PND module.
	Standard AOP The preferred profile to allow the user to configure between 1 and 11 connections.
	Generic Profile
	Provides a single connection and is required for older versions of Logix.
Connection Count	The number of class 1 CIP connections established between the ControlLogix CPU and the module. (1 to 11).
	Note: This value must match that configured in the Logix IO tree.
Logix Base Tag	The tagname of the ILX56-PND used for the input and output assembly. For example, if the module is in the local slot connected to a Logix controller the base tag will be Local:x (where x is the slot number). The base tagname is used when generating the Logix L5X file to automatically map the required data.

Table 3.1 - General configuration parameters

ProSoft Technology, Inc. Page 15 of 62

3.3.2 PROFINET

The *PROFINET* tab in the Configuration window is opened by either double-clicking on the module icon in the tree, or by right-clicking on the module icon and selecting **CONFIGURATION**.





Figure 3.7 - ILX56-PND PROFINET configuration

The PROFINET configuration consists of the following parameters:

Parameter	Description
Dynamic PN Name and IP Address	When selected, the ILX56-PND Device Name and Network settings (e.g., IP Address) are set by the PROFINET Controller connected to the ILX56-PND. The name and IP address set by the PROFINET Controller is non-volatile.
	When the option is not selected, the ILX56-PND PROFINET Device Name and Network settings are set to the values in this configuration page. The PROFINET Controller connected to the ILX56-PND is not able to change the Name or Network settings.
	Note: For TIA Portal utility users:
	When this parameter is enabled, TIA portal must have the Set IP address in the project option selected.
	When this parameter is not enabled, TIA portal must have the IP address is set directly at the device option selected.

ProSoft Technology, Inc.

Page 16 of 62



Instance	Note: Relevant when Dynamic PN Name and IP Address has not been selected.
Instance Name	The name used to identify the device on the PROFINET network.
Interface	Note: Relevant when Dynamic PN Name and IP Address has not been selected.
IP Address	The IP Address of the module on the PROFINET network.
Subnet Mask	The subnet mask to be used by the module/s on the PROFINET network.
Default Gateway	The IP Address of the Default Gateway to be used by the module/s on the PROFINET
	network. The gateway allows the module to communicate with PROFINET devices that
	are not on the same subnet.
Advanced Settings	
Logix Comms Fail	Specifies the PROFINET Device behavior when communication with Logix is lost.
	Stop or Continue
Logix Program Mode	Specifies the PROFINET Device behavior when the Logix controller is placed in
	PROGRAM mode. Stop or Continue
Ethernet Port 1 / 2	The Ethernet port speed selection.
	Auto – The Ethernet port speed will be auto-negotiated (100M or 1G).
	Fixed 100 Mbps FD – The Ethernet port speed will be fixed at 100Mbps.
	Fixed 1 Gbps FD – The Ethernet port speed will be fixed at 1 Gbps.

Table 3.2 - PROFINET configuration parameters

ProSoft Technology, Inc. Page 17 of 62

3.4 Slot Configuration

The *Slot Config* tab contains the module and sub-module slot configuration. The Slot Configuration allows the ILX56-PND to provide the implemented Slots to the PROFINET Controller, such that they can be added in the Connection Request from the PROFINET Controller.

Note: At least one Slot must be configured before the PLX50CU will allow the configuration to be downloaded to a ILX56-PND module.

3.4.1 Add Module

To add a module, either click on the **ADD MODULE** button in the *Slot Config* tab, or right-click and select the **ADD MODULE** context menu option.




Figure 3.8 - Slot Configuration

ProSoft Technology, Inc. Page 18 of 62

The Add Module window opens and lists all the available modules for the selected Slot Number for the ILX56-PND.




Figure 3.9 - Module Selection

The module selection can be narrowed by entering filter criteria for one or more of the following attributes: *Category*, *Module*, *Order Number*, and *Module Ident*

Note: The entered criteria can be removed by clicking on the **RESET** button.

Note: When entering filter criteria, it is recommended to use the wildcard character "*", before and after the criteria text. Example: *321 DI4*

Once the required module has been selected, click the $\mathbf{O}\kappa$ button. The selected module will be added to the Slot configuration.




Figure 3.10 - Slot configuration

ProSoft Technology, Inc. Page 19 of 62

3.4.2 Delete Module

To delete a module, right-click on the module and select **DELETE MODULE**.




Figure 3.11 – Delete Module

ProSoft Technology, Inc. Page 20 of 62

3.5 Mapping

The *Mapping* tab displays the relationship between the PROFINET device's input and output data and the resulting UDT tag structure in Logix.




Figure 3.12 – Device Mapping configuration

The items listed in the *Mapping* configuration table are automatically added and removed when a module/submodule is added or removed.

The *Mapping* table contains the following:

Column	Description
Slot	The slot or sub-slot position of the module or submodule. (Read only)
Module	The name of the module or submodule. (Read only)
I/O	The direction of the data flow. (Read only)
	Input: From device to controller
	Output: From controller to device.
Offset	The byte offset in the PROFINET device data structure (Read only)
Data Type	The PROFINET data type. (Read only)
Length	The data length in bytes. (Read only)
Tagname	The user configurable Tagname for the data point.
	This Tagname is used to generate the device specific UDT (user-defined data type) to be imported into Logix.
	Note: The Tagname must conform to the requirements of Logix tagnames / UDT member names. (No spaces or extended characters.)
	Note: Each Tagname must be unique across the entire PROFINET device.

ProSoft Technology, Inc. Page 21 of 62

User Manual

The data format to be used for the Logix device specific UDT. Depending on the corresponding PROFINET data type, the following options are available: None (The item is excluded from the Logix structure.) BOOL SINT INT DINT LINT REAL LREAL SINTArray PNIOStatus - A specific UDT to describe the:

Table 3.3 – Device Mapping configuration columns

IOPS – Input Output Object Provider Status IOCS – Input Output Object Consumer Status

ProSoft Technology, Inc. Page 22 of 62

3.6 Advanced

The Advanced tab contains the language, CRC, and assembly parameters.




Figure 3.13 – Device Advanced configuration

The Advanced tab contains the following parameters:

Parameter	Description
Device Config CRC	A checksum calculated on the entire device's configuration.
Mapping CRC	A checksum of the device configuration associated with data mapping.

Table 3.4 – Device Advanced configuration parameters

ProSoft Technology, Inc. Page 23 of 62

3.7 Module Download

Once the ILX56-PND configuration is complete, it must be downloaded to the module. The *Connection Path* of the module must be configured before downloading.

1 Right-click on the module and select the **CONNECTION PATH** option.




Figure 3.14 - Select Connection Path

2 The current *Connection Path* will be displayed. The new connection path can be entered manually or selected by using the *Target Browser*. To use the latter, select the **Browse** button.



Figure 3.15 - Enter Connection Path




Figure 3.16 - Target Browser

ProSoft Technology, Inc. Page 24 of 62

- 3 Click **OK**. The configured path will be used to connect to the module.
- 4 To initiate the download, right-click on the module and select the **DOWNLOAD** option.




Figure 3.17 - Selecting Download

5 Once complete, the user will be notified that the download was successful.




Figure 3.18 - Successful download

The PLX50 Configuration Utility will indicate the module will be in the *Online* state. The module's icon will have a green circle. The module is now configured and operational.




Figure 3.19 - Module online

ProSoft Technology, Inc. Page 25 of 62

3.8 Studio 5000 Configuration

There are two profile options for integrating the ILX56-PND into Logix:

- Standard (ILX56-PND) Add-On-Profile (AOP)
- Generic Profile (1756-Module)

Note: The minimum Studio 5000 version that can be used is V16. The preferred implementation makes use of an Add-On Profile (AOP) for the 1756 Backplane, which requires V30 and newer. Versions prior to V30 require the use of a Generic Profile.

Note: The choice of profile selected in Studio 5000 / RSLogix 5000 must match that configured in the PLX50 Configuration Utility.

3.8.1 Standard Add-On Profile

3.8.1.1 Installing the Add-On Profile (AOP)

Before the ILX56-PND module AOP can be added into the Logix I/O tree, it must first be installed on that system. The user will need to download the AOP from www.prosoft-technology.com. Once downloaded, extract the zip file, run the MPSetup.exe file, and follow the on-screen instructions.

ProSoft Technology, Inc. Page 26 of 62

3.8.1.2 Add Module to I/O Configuration

This sections adds the AOP to the Logix IO Configuration (tree).

1 Right-click on the 1756 BACKPLANE and select the New MODULE option.




Figure 3.20 - Adding a New Module

2 In the Select Module Type dialog, enter the ILX56-PND name into the catalog filter to find the ILX56-PND AOP.




Figure 3.21 – Selecting the module

3 Select the ILX56-PND and click CREATE.

ProSoft Technology, Inc. Page 27 of 62

4 In the *New Module* dialog configure the module *Name* and *Slot* as a minimum to complete the instantiation.

Note: The module *Name* must match the *Instance Name* configured in the PLX50 Configuration Utility.




Figure 3.22 – Module instantiation

5 Once the instantiation is complete the module will appear in the Logix IO tree.



Figure 3.23 - Logix IO tree

6 The *Module Defined Data Types* will be automatically created during the instantiation process.

ProSoft Technology, Inc. Page 28 of 62

3.8.1.3 PLX50 Configuration Utility Project File

The ILX56-PND AOP allows the user to save the PLX50 Configuration Utility project file in the AOP as well as launch PLX50 Configuration Utility from the AOP.




Figure 3.24 – AOP - PLX50 Configuration Utility

ProSoft Technology, Inc.

Page 29 of 62

When no PLX50 Configuration Utility project has been defined, the user can *Browse* for an existing PLX50 Configuration Utility project. If no PLX50 Configuration Utility project has been created, the user can manually enter in the project file name in the *PLX50 Configuration Utility Project File* textbox and select the **LAUNCH PLX50 CONFIGURATION UTILITY** button.




Figure 3.25 - AOP - Launch PLX50 Configuration Utility

Note: Once the file name has been entered, the user will need to click **APPLY** before the **LAUNCH PLX50 CONFIGURATION UTILITY** button will become available.

ProSoft Technology, Inc. Page 30 of 62

3.8.2 Generic Profile

For older versions of Studio 5000 / RSLogix 5000, the use of the Generic Profile is required.

To add the **Generic 1756-Module** profile in the Logix *IO Configuration* (tree):

1 Right-click 1756 BACKPLANE and select the NEW MODULE option.




Figure 3.26 - Adding a New Module

2 In the Select Module Type dialog, the Module Type Category Filters search field can be used search for "Generic" modules as shown in the following figure.




Figure 3.27 – Selecting the Generic module

3 Locate and select the 1756-MODULE and click the CREATE button.

ProSoft Technology, Inc. Page 31 of 62

4 In the *New Module* dialog configure the module *Name*, *Slot*, and *Connection Parameters* as a minimum to complete the instantiation.

Note: The module *Name* must match the *Instance Name* configured in the PLX50 Configuration Utility.




Figure 3.28 - Generic Module instantiation

5 The required Connection Parameters are as follows:

Parameter	Description	
Input Instance	132	
Input Size	500 (bytes)	
Output Instance	133	
Output Size	496 (bytes)	
Configuration Instance	102	
Configuration Size	0 (bytes)	

Table 3.5 - Generic Connection Parameters

6 Once the instantiation is complete the module will appear in the Logix IO tree.



Figure 3.29 - Logix IO tree

ProSoft Technology, Inc. Page 32 of 62

3.9 Logix Mapping

The PLX50 Configuration Utility will generate the required UDTs and Routines to map the PROFINET input and output data. The user will need to generate the required Logix and UDTs by right-clicking on the module in the PLX50 Configuration Utility and selecting the **GENERATE LOGIX L5X** option.

Note: The user will need to ensure that the Logix Base Tag is correct for the generated Logix L5X code to work. The base tag will be the tag name for the module input and output assemblies in the Logix controller owning the module.

For example, if the ILX56-PND is in the same local rack as the Logix controller owning it, the Logix Base Tag will be *Local:xx* (where *xx* is the slot number of the module). Below is an example where the ILX56-PND is in slot 1 of the local rack.




Figure 3.30 - Logix Base tag assignment in PLX50 Configuration Utility




Figure 3.31 – Logix Base tag assignment in Studio 5000

ProSoft Technology, Inc. Page 33 of 62

If the module is in a remote rack, the user will need to enter the Logix Base Tag based on the name of the remote rack (see the example below):




Figure 3.32 - Logix Base tag assignment in PLX50 Configuration Utility




Figure 3.33 – Logix Base tag assignment in Studio 5000

ProSoft Technology, Inc. Page 34 of 62

To generate the mapping Logix L5X file, right-click on the ILX56-PND module and select the **GENERATE LOGIX L5X** option.




Figure 3.34 – Selecting Generate Logix L5X

The user will then be prompted to select a suitable file name and path for the L5X file.




Figure 3.35 – Selecting the Logix L5X file name.

ProSoft Technology, Inc. Page 35 of 62

This L5X file can now be imported into the Studio 5000 project by right-clicking on a suitable **PROGRAM**, then click **ADD** > **IMPORT ROUTINE**.




Figure 3.36 – Importing the L5X file into Studio 5000

In the file open dialog, select the previously created L5X file and press OK.

The import will create the following:

- Mapping Routine
- Multiple UDT (User-Defined Data Types)
- Multiple Controller Tags

Since the imported mapping routine is not a *Main Routine*, it will need to be called from the current *Main Routine*.



Figure 3.37 - Calling the mapping routine

ProSoft Technology, Inc. Page 36 of 62

The following shows an example of the items created by importing the L5X file.




Figure 3.38 - Imported Logix Objects

A number of ILX56 specific (UDT) tags are created for both the ILX56-PND Controller as well as the configured PROFINET devices. These structures are described in the following section.

ProSoft Technology, Inc. Page 37 of 62

4 Operation

4.1 Logix Operation

When the ILX56-PND has been configured for Logix communication, it will exchange data with a Logix controller by adding the ILX56-PND in the IO tree and establishing a Class 1 connection. Once the ILX56-PND and Logix controller have been configured, the ILX56-PND will start exchanging data with the PROFINET controllers.

Note: The module input and output assembly of each connection will be an undecorated array of bytes. The imported Logix routine (generated by PLX50 Configuration Utility) will copy this data between the decorated tags (UDT) and the input and output assemblies.

4.1.1 PND Module Status

The controller Status tag displays the status of the PROFINET Device and other ILX56-PND module related diagnostics.

Name	Value •	Style	Data Type
▲ Local:1:l1	{}		PS:ILX56_PND_InStatus:I:0
Local:1:I1.ConnectionFaulted	0	Decimal	BOOL
▶ Local:1:I1.DeviceStatus	119	Decimal	DINT
Local:1:l1.ConfigValid	1	Decimal	BOOL
Local:1:I1.Owned	1	Decimal	BOOL
Local:1:I1.EthernetPort1	1	Decimal	BOOL
Local:1:I1.EthernetPort2	0	Decimal	BOOL
Local:1:I1.ControllerMode	1	Decimal	BOOL
Local:1:l1.SDCard	1	Decimal	BOOL
Local:1:I1.DataExchangeActive	1	Decimal	BOOL
Local:1:I1.DisabledByOutputAssembly	0	Decimal	BOOL
Local:1:I1.DeviceError	0	Decimal	BOOL
Local:1:I1.MappingCRCMismatch	0	Decimal	BOOL
Local:1:I1.ModuleMismatch	0	Decimal	BOOL
Local:1:I1.S2RedundantConnection	0	Decimal	BOOL
▶ Local:1:I1.ConfigCRC	16#cd69	Hex	INT
▶ Local:1:I1.IPAddress	{}	Decimal	INT[4]
▶ Local:1:I1.MRPState	0	Decimal	SINT
▶ Local:1:I1.DeviceMappingCRC	16#f79c	Hex	INT

Figure 4.1 – Logix Module Status tag

ProSoft Technology, Inc. Page 38 of 62

The items contained within the controller status structure are as follows:

Tag	Description
ConnectionFaulted	Indicates if a connection fault has been detected.
	1 – Connection fault
	0 – No connection fault
DeviceStatus	Indicates the status of the module. It reflects the status on all Bool data types in
	the following Controller Tags.
ConfigValid	Configuration has been downloaded to the ILX56-PND and is being executed. 1 – ILX56-PND has been successfully configured.
	0 – ILX56-PND is not configured.
Owned	Indicates if the ILX56-PND is owned by a Logix Controller with a connection
	count matching that configured in PLX50 Configuration Utility.
	1 – ILX56-PND is connected.
	0 – ILX56-PND is not connected.
EthernetPort1	Indicates the link status of the first Ethernet port (Port 0).
	1 – Active Ethernet link
	0 – No Ethernet link
EthernetPort2	Indicates the link status of the second Ethernet port (Port 1).
	1 – Active Ethernet link
	0 – No Ethernet link
ControllerMode	Indicates if the connected Logix controller is in RUN mode.
Controllerinious	1 – RUN mode
	0 – PROGRAM / FAULT mode
SDCard	Indicates if an SD Card is installed.
ob dard	1 – SD Card detected
	0 – No SD Card
DataExchangeActive	Indicates if the device is configured and exchanging data on the PROFINET
Data Exorial 1907 to 11 Vo	network.
	1 – Device is active and exchanging data
	Device is not exchanging data
	The user must ensure that all application code making use of data from a
	device first checks that the <i>DataExchangeActive</i> bit is 1.
DisabledByOutputAssembly	Indicates that the device has been Disabled for data exchange in the ILX56-
Bloadicaby Carpati tocombiy	PND device disable control bit.
	1 – Device has been disabled for data exchange
	Device has been enabled for data exchange
DeviceFrror	Indicates an error with the device.
DeviceZirei	1 – Device has an error.
	0 – Device has no error.
	2 Device has he show
	Note: This Error flag is transient and will clear once the error condition has
	been rectified.
MappingCRCMismatch	If there is a mismatch in the mapping between Logix and the ILX56-PND, it can
	result in data appearing in the incorrect location. The user can be sending
	incorrect data to a device which can have unpredicted results.
	0 – The mapping for the output data is correct.
	1 – There is a mapping mismatch in the output data.
ModuleMismatch	One or more of the configured PROFINET modules in the ILX56-PND device
	does not match the configuration or is missing.
	0 – Modules Match (Ok)
	1 – Mismatch
	Indicates that the Cyclic Connection to the ILX56-PND module is an S2
S2RedundantConnection	INDICATES THAT THE CACHE CONTRECTION TO THE IT ASSOCIATED THOUGHERS SO SA
S2RedundantConnection	·
S2RedundantConnection	Redundant Connection. 0 – Normal non-redundant connection active.

ProSoft Technology, Inc.

Page 39 of 62

ConfigCRC	The signature of the configuration currently executing on the module.
ModuleIPAddress	Indicates the IP address of the ILX56-PND module.
MRPState Indicates the MRP state of the controller:	
	0 – Disabled
	1 – Open Ring
	2 – Closed Ring
DeviceMappingCRC	The checksum of the Mapping for the specific device.

Table 4.1 – Logix Controller Status tag

4.1.2 PND Control

The user will need to set the PROFINET Operating mode from the ILX56-PND Logix output assembly in the Logix controller.

Name	Value •	Style	Data Type
▲ Local:1:01	{}		PS:ILX56_PND_OutControl:O:0
▶ Local:1:O1.PNDControl	0	Decimal	INT
▶ Local:1:O1.DeviceDisable	{}		PS_ILX56_PND_DeviceList_Struct:IO:0
▶ Local:1:O1.SystemTime	DT#2024-07-04-13:56:35.832_027(UTC+02:00)	Date/Time	LINT
▶ Local:1:O1.DeviceMappingCRC	16#f79c	Hex	INT

Figure 4.2 - Logix Controller Control tag

Tag	Description	
PNDControl	This is currently reserved.	
DeviceDisable	These bits disable the ILX56-PND device on the PROFINET network for data exchange. Only the first bit is used to enable or disable the PROFINET data exchange. The other bits are reserved. When the first bit is set '1' then the device will not enter data exchange and when the bit is off '0' the device will enter cyclic data exchange. Bit 0 – ILX56-PND device is disabled for data exchange Bit 1 to 63 – Reserved	
SystemTime	The system time in UTC.	
DeviceMappingCRC	The checksum of the mapping that was applied by the generated Logix code used to verify if the mapping being used is valid.	

Table 4.2 - Logix Controller Control tag

The user will be able to see if there are any faults (e.g. configured device not found) by:

- Viewing the LEDs of the ILX56-PND (see section 8.1 LEDs for more details)
- Going online with the module in the PLX50 Configuration Utility and viewing the ILX56-PND Diagnostics
- Viewing the input assembly of the ILX56-PND in Logix.

ProSoft Technology, Inc.

Page 40 of 62

4.1.3 IO Data Status (IOPS / IOCS)

Contained within the ILX56-PND module's input and output configuration, there will be a number of IOPS (Input Output Object Provider Status) and IOCS (Input Output Object Consumer Status) objects. There are typically one of these per device module.

- The IOPS provides information on the status of the produced data.
- The IOCS provides information on the status of the consumed data.

Exposing these items to the Logix application code allows the monitoring of the status of input data. It also allows the application to control the status of the data being sent to the output devices.

In a typical data exchange with an **output** device, as shown below, the controller sends the output data and the IOPS. The IOPS can be controlled by the application code, perhaps flagging the data as bad under certain conditions which in turn could cause the output device to a fail-safe condition. The application code can also monitor the IOCS for confirmation that the device received the latest data.




Figure 4.3 – Typical Output Device Data Exchange

In a typical data exchange with an **input** device, as shown below, the device sends the output data and the IOPS to the controller. The application code can use the IOPS to determine the quality of the data provided.




Figure 4.4 - Typical Input Device Data Exchange

ProSoft Technology, Inc. Page 41 of 62

Both the IOPS and IOCS are represented in the Logix structures using a common UDT structure, which expands the typically 1 byte status to a more Logix readable structure.




Figure 4.5 - IO Data Status Specific tag

The IO Data Status structure comprises the following:

Parameter	Description
Status	
DataBad	Indicates the Data is bad.
	0 – Data is good
	1 – Data is bad
BadDetectedBySubslot	Indicates that the bad data is being flagged at the Subslot level.
BadDetectedBySlot	Indicates that the bad data is being flagged at the Slot level.
BadDetectedByIODevice	Indicates that the bad data is being flagged at the IO Device level.
BadDetectedByIOController	Indicates that the bad data is being flagged at the IO Controller level.

Table 4.3 - IO Data Status Specific tag

ProSoft Technology, Inc.

Page 42 of 62

5 SD Card

The ILX56-PND supports an SD Card for disaster recovery. The SD Card can be pre-loaded with the required firmware and/or application configuration.




Figure 5.1 - Module Bottom View - SD Card Slot

Note: The user will need to ensure that the SD Card has been formatted for FAT32.

Note: All files must be copied into the root directory of the SD Card. The module will not use files located in folders.

5.1 Firmware

The user can copy the required firmware (which can be downloaded from www.prosoft-technology.com) onto the root directory of the SD Card.




Figure 5.2 - SD Card - Firmware file

Note: The filename of the firmware file must not be changed. The specific module will use only the firmware that is valid (e.g. the ILX56-PND will only use the BIN firmware file).

Note: If more than one firmware file with different firmware revisions of the same product is on the SD Card, it can cause the module to constantly firmware upgrade the module.

If a faulty module is replaced, the user can insert the SD Card with the firmware file into the new module. While the module is booting it can detect if the firmware on the new module is different from that on the SD Card. If yes, the firmware will either be upgraded or downgraded to the firmware revision on the SD Card.

ProSoft Technology, Inc. Page 43 of 62

5.2 Configuration

If a faulty module is replaced, the user can insert the SD Card with the configuration file into the new module. The new module will determine if the configuration on the SD Card is different than the currently loaded configuration (even when there is no configuration on the module). If different, the configuration on the SD Card will be downloaded into the module's NV memory before the module starts executing.




Figure 5.3 - SD Card - Configuration file

Once the user has created the necessary application configuration in the PLX50 Configuration Utility, the configuration can be exported to a file that can be used on the SD Card. The user can copy this exported file into the root directory of the SD Card.

5.2.1 Save Configuration File to SD Card

When the SD Card is inserted into the ILX56-PND module, the **SAVE CONFIGURATION TO SD CARD** option will become available. When this is selected, the current application configuration is saved on to the SD Card.

ProSoft Technology, Inc.

Page 44 of 62

5.2.2 Exporting the Configuration File

To export the configuration, right-click on the ILX56-PND and select the **EXPORT CONFIGURATION FILE** option.




Figure 5.4 - Configuration Export for SD Card




Figure 5.5 – Configuration Export for SD Card

Note: The filename of the configuration file must not be changed. The specific module will use only the configuration that is valid (e.g. the ILX56-PND will only use the BIN configuration file).

ProSoft Technology, Inc. Page 45 of 62

6 Firmware upgrade

The ILX56-PND allows the user to upgrade the module firmware in the field by using the PLX50 Configuration Utility.

In the PLX50 Configuration Utility go to the *Tools* menu and select the **DEVICEFLASH** option.




Figure 6.1 - DeviceFlash Tool

The user will need to select the appropriate .AFB binary file to upgrade the ILX56-PND firmware then click **OPEN**.




Figure 6.2 - Select the AFB binary

ProSoft Technology, Inc. Page 46 of 62




Figure 6.3 - Select the correct ILX56-PND module

Once the firmware upgrade is complete, the *Device Flash* dialog will provide the user with the details of the updated module.




Figure 6.4 – ILX56-PND successfully updated.

Note: The ILX56-PND firmware is digitally signed so the user will only be able to flash the ILX56-PND with authorized firmware.

ProSoft Technology, Inc.

Page 47 of 62

7 Media Redundancy Protocol (MRP)

Media Redundancy Protocol (MRP) allows PROFINET devices to be connected in an Ethernet ring topology which provides protection against single-cable-fault communication failures.

An MRP ring consists of multiple MRP clients and a single MRP manager. The manager monitors the integrity of the ring by sending Test Frames out one port and expects them to appear on the other port. When the ring is healthy the manager blocks all traffic transfer between its ports.




Figure 7.1 – MRP Ring

If the ring is broken (due to a cable failure or disconnection) then the MRP manager must notify the other client devices in the ring that there is a failure and then switch its own ports to a line topology, that is, passing packets between its own ports.

This process typically takes a few milliseconds, without the cyclic data exchange between the controller and devices being adversely affected.

ProSoft Technology, Inc. Page 48 of 62

7.1 Basic Rules

All devices in a ring must comply with the following:

- 1) All devices must support MRP and have MRP enabled.
- 2) One device must be configured as an MRP Manager (MRM), and all the other devices must be configured as MRP Clients (MRC).
- 3) All devices must be configured with the same MRP Domain.
- 4) Devices must be connected to the ring using their two configured ring ports.
- 5) All partner ports must have the same configuration.

Note: When commissioning an MRP ring ensure that all devices have been correctly configured before closing the ring. Failure to do so may cause a complete network failure and prevent further configuration of some, or all, of the devices.

Note: The IO Update Time and WatchDog Factor for each device must be configured such that the MRP fault recovery will not result in the cyclic connection timing out.

ProSoft Technology, Inc. Page 49 of 62

8 Diagnostics

8.1 **LEDs**

The module provides 3 diagnostic LEDs and a 4-character alpha-numeric LED display for diagnostics purposes as shown below:




Figure 8.1 – ILX56-PND LEDs

ProSoft Technology, Inc. Page 50 of 62

A description of each LED is given in the table below.

LED	Description
DS	Indicates the status of the PROFINET network.
	Off – No communication on the PROFINET network.
	Solid Red – The device is not exchanging cyclic data.
	Flashing Green – The device is exchanging cyclic data with the PROFINET controller, but there are errors.
	Solid Green – The device is exchanging cyclic data with the PROFINET controller without any errors.
PM	This LED is reserved.
OK	Indicates information regarding the system-level operation of the module.
	Flashing Red – The module is not operating correctly. For example, if the module application firmware has been corrupted or there is a hardware fault.
	Flashing Green – The module has booted and is running correctly without any application configuration loaded.
	Solid Green – The module has booted and is running correctly with application configuration loaded.

Table 8.1 – Module LED operation

A description of each alphanumeric display message is given in the table below.

LED Text	Description
TEST	The module is busy testing all hardware during bootup.
OK	The module has successfully booted, and all hardware testing has passed.
No Name Assigned	The module does not have a PROFINET name assigned to it (when the
	Dynamically Assign bit has been set).
	Note: If a name has been assigned then it will be scrolled across the LED display.
IP x.x.x.x	The IP address of the local ILX56-PND module.
No IB Assigned	The module does not have an IP address assigned to it (when the Dynamically
No IP Assigned	Assign bit has been set).
No Config Loaded	No configuration has been loaded onto the ILX56-PND.

Table 8.2 - Module LED operation

The module LED will also display the instance name of the module configured in PLX50 Configuration Utility.

ProSoft Technology, Inc. Page 51 of 62

8.1 Module Status Monitoring

The ILX56-PND provides a range of statistics that assists with module operation, maintenance, and fault finding. The statistics can be accessed in full by the PLX50 Configuration Utility.

To view the module's status in the PLX50 Configuration Utility environment, the ILX56-PND must be online. If the module is not already Online (following a recent configuration download), then right-click on the module and select the **GO ONLINE** option.




Figure 8.2 - Selecting to Go Online

The Online mode is indicated by the green circle behind the module in the Project Explorer tree.

The Status monitoring window can be opened by either double-clicking on the *Status* item in the Project Explorer tree, or by right-clicking on the module and selecting **STATUS**.




Figure 8.3 - Selecting ILX56-PND Online Status monitoring

The status window contains multiple tabs to display the current status of the module.

ProSoft Technology, Inc. Page 52 of 62

8.1.1 General

The *General* tab displays the following general parameters:




Figure 8.4 – ILX56-PND Status monitoring - General

Parameter	Description
Configuration	Indicates if the downloaded configuration is valid and executing.
	Valid – Configuration is valid.
	Not Valid – Configuration is blank or corrupt.
Logix State	Indicates if the module is currently owned (Class 1) by a Logix controller and the state of the
9	controller:
	Not Owned – Logic controller not connected.
	Owned - Run – Controller is connected and in RUN mode
	Owned Program – Controller is connected and in PROGRAM, FAULT, or TEST mode.
IP Address	The IP address of the ILX56-PND.
MRP Status	The current MRP status:
	Disabled – MRP is disabled.
	Open Ring – The MRP ring is open.
	Closed Ring – The MRP ring is closed.
Firmware Revision	The application firmware revision currently executing.
Configuration Signature	The signature of the configuration currently executing on the module.
Serial Number	Displays the module's serial number.
Logix Slot	The current slot in which the module resides of the ControlLogix rack.
Temperature	The internal temperature of the module.
Processor Scan	The amount of time (microseconds) taken by the module's processor in the last scan.
Up Time	Indicates the elapsed time since the module was powered-up.
SD Card	Indicates if a SD Card has been inserted into the module.
MAC Address Chassis,	The MAC Addresses assigned to the PROFINET interface.
Port 1, and Port 2	-

ProSoft Technology, Inc. Page 53 of 62

Ethernet Ports 1 & 2	
Status	The current link status of the Ethernet port:
	Up-1G – Port has an active Ethernet link at 1 Gbps speed.
	Up-100M – Port has an active Ethernet link at 100 Mbps speed.
	Down – Port has no Ethernet link.
MRP Link Down Device	The suspected device at which the MRP ring has been broken.
	Only applicable when MRP is enabled.

Table 8.3 – Parameters displayed in the Status Monitoring – General Tab

8.1.2 Device Status

The *General* tab displays the following general parameters:



Figure 8.5 – Device Status monitoring - General

Parameter	Description
Device Status	The current status of the device:
	Data Exchange Active – The device is exchanging cyclic data with the ILX56-PND.
	Disabled (Logix) – The device has been disabled for cyclic data exchange by the Logix controller using the ILX56-PND output assembly. Enabled (Logix) – The device has been enabled for cyclic data exchange by the Logix
	controller using the ILX56-PND output assembly.
	Device Error – Device Error flag: Either the controller has disconnected from the device, or the quality of the IOPS (Input Output Object Provider Status) is bad. The latter may be an indication that the PROFINET controller is not in RUN mode. Device Ok – No Device Error
	CRC Mismatch (Logix) – Indicates the mapping from the Logix controller does not match the configured mapping in the ILX56-PND.

ProSoft Technology, Inc. Page 54 of 62

	CRC Match (Logix) – Indicates the mapping from the Logix controller matches the configured mapping in the ILX56-PND.
	Module Slot Mismatch – In the connection establishment from the PROFINET Controller, the incorrect Slot was sent in the module configuration. Module Slot Match – In the connection establishment from the PROFINET Controller, the slots configured in the ILX56-PND matched that expected by the controller.
	 S2 Redundancy Disabled – The device connection to the PROFINET Controller is a standard single Controller connection. S2 Redundancy Enabled – The device connection to the PROFINET Controller is an S2 Redundant controller.
IP Address	The configured IP address for the device.
Instance Name	The configured instance name for the device.

Table 8.4 – Device Status Monitoring – General Tab

8.1.3 PROFINET Statistics

The PROFINET Statistics tab displays the following general parameters:




Figure 8.6 – ILX56-PND Status monitoring – PROFINET Statistics

Parameter	Description
Cyclic Tx Packet Count	The number of cyclic PROFINET packets transmitted.
Cyclic Rx Packet Count	The number of cyclic PROFINET packets received.
Acyclic Tx Packet Count	The number of acyclic PROFINET packets transmitted.
Acyclic Rx Packet Count	The number of acyclic PROFINET packets received.
No Reply Count	The number of ILX56-PND PROFINET requests where the device did not respond.
Device Reconnect Count	The number of device connection requests sent.

Table 8.5 - Parameters displayed in the Status Monitoring - General Statistics Tab

ProSoft Technology, Inc.

Page 55 of 62

8.1.4 Advanced

The Advanced tab displays various internal and low-level, diagnostics of the ILX56-PND.




Figure 8.7 – ILX56-PND Status monitoring – Advanced Tab

Description
The boot-up status of the backplane controller.
The firmware revision of the backplane controller.
The bootloader version of the backplane controller.
The communication status to the cryptography processor.
The primary module MAC address.
The measured backplane voltage.
The measure backplane current in mA.
The calculated backplane power consumption in W.
The current status of the DIP switches.
The status of the DIP switches at Boot-up.

Table 8.6 – Parameters displayed in the Status Monitoring – Advanced Tab

ProSoft Technology, Inc. Page 56 of 62

8.2 Module Event Log

The ILX56-PND module logs various diagnostic records to an internal event log. These logs are stored in non-volatile memory and can be displayed using the PLX50 Configuration Utility. To view them in the PLX50 Configuration Utility, select the **EVENT VIEWER** option.




Figure 8.8 - Selecting the module Event Log

The *Event Viewer* window will open and automatically read all the events from the module. The log entries are sorted with the latest record at the top. Custom sorting is achieved by double-clicking on the column headings.

ProSoft Technology, Inc. Page 57 of 62




Figure 8.9 - Module Event Log

The log can also be stored to a file for future analysis, by clicking the **SAVE** button in the tool menu. To view previously saved files, use the *Event Log Viewer* option under the *Tools* menu.

ProSoft Technology, Inc. Page 58 of 62

9 Technical Specifications

9.1 Electrical

Description	
600 mA @ 5 VDC	
2 mA @ 24 VDC	
IP20, NEMA/UL Open Type	
0°C to 60°C (32°F to 140°F)	
ILX56-PND-CC: -20°C to 70°C (-4°F to 158°F)	
Yes, terminal based	
IEC61000-6-4	
EN 61000-4-2	
IEC 61000-4-3	
EFT: IEC 61000-4-4	
Surge: IEC 61000-4-5	
IEC 61000-4-6	

Table 9.1 – Electrical specification

9.2 PROFINET

Specification	Description
PROFINET Device	Supported
Media Redundancy Protocol (MRP)	Client Supported
PROFINET Conformance Level	В
S2 Redundancy	Supported

Table 9.2 - PROFINET specification

9.3 ControlLogix

Specification	Description
Class 1 Connections	Maximum 11 x Class 1 connections supported.
Minimum Requested Packet	2ms for connection count <= 4
Interval (RPI)	10ms for connection count > 4
UCMM Acyclic Messaging	Supported
Class 3 Acyclic Messaging	Supported

Table 9.3 - ControlLogix specification

9.4 Certifications

Please visit our website: www.prosoft-technology.com

ProSoft Technology, Inc. Page 59 of 62

10 Appendix

10.1 PROFINET Response Error Codes

The response status consists of four error codes:

- ErrorCode
- ErrorDecode
- ErrorCode1
- ErrorCode2

The definition of *ErrorCode1* and *ErrorCode2* will depend on the values of *ErrorCode* and *ErrorDecode*.

Note: There are many error code definitions, this section provides details relevant to Explicit Acyclic Messaging.

ErrorCode	ErrorDecode	ErrorCode1	ErrorCode2	Description
0x00	-	-	-	No Error
0x81	0x80	0xA0	-	Application Error
(PNIO)	(PNIORW)			Read Error
0x81	0x80	0xA1	-	Application Error
(PNIO)	(PNIORW)			Write Error
0x81	0x80	0xA2	-	Application Error
(PNIO)	(PNIORW)			Module Failure
0x81	0x80	0xA7	-	Application Error
(PNIO)	(PNIORW)			Busy
0x81	0x80	0xA8	-	Application Error
(PNIO)	(PNIORW)			Feature Not Supported
0x81	0x80	0xB0	-	Access Error
(PNIO)	(PNIORW)			Invalid Index
0x81	0x80	0xB1	-	Access Error
(PNIO)	(PNIORW)			Write Length Error
0x81	0x80	0xB2	-	Access Error
(PNIO)	(PNIORW)			Invalid Slot / Subslot
0x81	0x80	0xB3	-	Access Error
(PNIO)	(PNIORW)			Type Conflict
0x81	0x80	0xB4	-	Access Error
(PNIO)	(PNIORW)			Invalid Area / API
0x81	0x80	0xB5	-	Access Error
(PNIO)	(PNIORW)			State Conflict
0x81	0x80	0xB6	-	Access Error
(PNIO)	(PNIORW)			Access Denied
0x81	0x80	0xB7	-	Access Error
(PNIO)	(PNIORW)			Invalid Range
0x81	0x80	0xB8	-	Access Error
(PNIO)	(PNIORW)			Invalid Parameter
0x81	0x80	0xB9	-	Access Error
(PNIO)	(PNIORW)			Invalid Type
0x81	0x80	0xBA	-	Access Error
(PNIO)	(PNIORW)			Backup
0x81	0x80	0xC0	-	Resource Error

ProSoft Technology, Inc.

Page 60 of 62

(PNIO)	(PNIORW)			Read Constraint Conflict	
0x81	0x80	0xC1	-	Resource Error	
(PNIO)	(PNIORW)			Write Constraint Conflict	
0x81	0x80	0xC2	-	Resource Error	
(PNIO)	(PNIORW)			Resource Busy	
0x81	0x80	0xC3	-	Resource Error	
(PNIO)	(PNIORW)			Resource Unavailable	

Table 10.1 - Error Response codes

ProSoft Technology, Inc. Page 61 of 62

11 Support, Service, and Warranty

11.1 Contacting Technical Support

ProSoft Technology, Inc. is committed to providing the most efficient and effective support possible. Before calling, please gather the following information to assist in expediting this process:

- 1 Product Version Number
- 2 System architecture
- 3 Network details

If the issue is hardware related, we will also need information regarding:

- 1 Module configuration and associated ladder files, if any
- 2 Module operation and any unusual behavior
- 3 Configuration/Debug status information
- 4 LED patterns
- 5 Details about the interfaced serial, Ethernet or Fieldbus devices

North America (Corporate Location)	Europe / Middle East / Africa Regional Office
Phone: +1 661-716-5100	Phone: +33.(0)5.34.36.87.20
ps.prosofttechnology@belden.com	ps.europe@belden.com
Languages spoken: English, Spanish	Languages spoken: English, French, Hindi, Italian
REGIONAL TECH SUPPORT	REGIONAL TECH SUPPORT
ps.support@belden.com	ps.support.emea@belden.com
Latin America Regional Office	Asia Pacific Regional Office
Phone: +52.222.264.1814	Phone: +60.3.2247.1898
ps.latinam@belden.com	ps.asiapc@belden.com
Languages spoken: English, Spanish,	Languages spoken: Bahasa, Chinese, English,
Portuguese	Hindi, Japanese, Korean, Malay
REGIONAL TECH SUPPORT	REGIONAL TECH SUPPORT
ps.support.la@belden.com	ps.support.ap@belden.com

For additional ProSoft Technology contacts in your area, please visit: www.prosoft-technology.com/About-Us/Contact-Us

11.2 Warranty Information

For complete details regarding ProSoft Technology's legal terms and conditions, please see:

www.prosoft-technology.com/ProSoft-Technology-Legal-Terms-and-Conditions

For Return Material Authorization information, please see: www.prosoft-technology.com/Services-Support/Return-Material-Instructions

ProSoft Technology, Inc. Page 62 of 62